

- Introduction
- For your own safety
- System description
- Art. no. 57140 Communication module RS232
- Serial communication protocols
- General data
- Technical data

CUBE20S Expansion manual

Communication module RS232

This document is valid for the following products:

Name	Art. no.
CUBE20S system	57140
Communication module RS232	
Communication modules incl. base	

Status

Manual no.: 57140_hdb_en_10

Language: EN

Version: 1.0

Date: 22.4.14

Contact

Murrelektronik GmbH

Falkenstraße 3

D-71570 Oppenweiler

Phone +49 (0) 7191 47-0

Fax +49 (0) 7191 47-491000

info@murrelektronik.de

Table of contents

1	Introduction	5
1.1	Service and support	5
1.2	Introduction / about this document	6
1.3	Applicable documents	6
1.4	Symbols	6
1.5	Trademarks	7
2	For your own safety	8
2.1	Target group	8
2.2	Intended purpose	8
2.3	General safety instructions	8
2.4	Notes on electrostatically sensitive equipment	9
2.5	EMC installation guidelines	9
2.6	Notes on spare parts and accessories	10
2.7	Environmentally friendly disposal	11
2.8	EC Declaration of Conformity	11
2.9	Warranty and liability	11
3	System description	12
3.1	System	12
3.2	Dimensions	15
3.3	Mounting	16
3.4	Disassembling and replacing modules	20
3.5	Wiring	26
3.6	Troubleshooting - LEDs	32
4	Art. no. 57140 Communication module RS232	34
4.1	Features	34
4.2	Design	34
4.3	Quick start	39
4.4	Input/output range	40
4.5	Principle of the backplane bus communication	41
4.6	Backplane bus communication	52
4.7	Diagnostic data	59
5	Serial communication protocols	61
5.1	Overview	61
5.2	ASCII	62
5.3	STX/ETX	66
5.4	3964(R)	70
5.5	Modbus	75
5.6	Modbus use	78
5.7	Modbus function codes	82
5.8	Modbus - Error messages	86

6	General data	87
<hr/>		
7	Technical data	89
7.1	Protocols	89
<hr/>		
8	Annex	91
8.1	Accessories	91
8.2	Glossary	92
8.3	Legal information	93

1 Introduction

1.1 Service and support

Sales	Our sales staff in the company, field service and technicians will support you at all times.
CONNECTIVITY system consultants	<p>Our system consultants are your competent contact persons when you want to develop CONNECTIVITY solutions. Together with you, they find the optimum solutions for your electrical installations.</p> <p>Our CONNECTIVITY consultants find ways that help you to permanently improve the competitiveness of your machines and plants.</p>
Customer Service Center (CSC)	<p>Our staff of the Customer Service Center will help you with all questions concerning installation and set-up. They support you, for example, if you have problems when combining hardware and software products of different manufacturers.</p> <p>There are numerous support tools and possibilities for measurements - both for fieldbus systems and electromagnetic interference.</p> <p>Please do not hesitate to call us on +49 (0) 7191 47-2050 or send us an e-mail to: csc@murrelektronik.de.</p>
Service addresses	<p>Please see our website for your contact person:</p> <p>www.murrelektronik.com</p>

1.2 Introduction / about this document

Function of this document

This document describes the use of the module Communication module RS232 from the Cube20S system of Murrelektronik GmbH. It includes a description of the design, engineering and application.

1.3 Applicable documents

Applicable documents

Document	Location
Operating manual	Online shop of Murrelektronik GmbH

1.4 Symbols

This document includes information and notes that have to be observed for your own safety and to avoid personal and material damage. They are characterized as follows:



DANGER!

Immediate danger

→ Failure to observe this warning involves an imminent risk of death or serious injuries!



WARNING!

Possible danger

→ Failure to observe this warning may cause death or serious injuries.



CAUTION!

Low-risk danger

→ Failure to observe this warning causes minor to moderate injuries.

NOTICE

Risk of material damage

→ Failure to observe this warning causes material damage.



NOTE

Other technical information and notes of Murrelektronik GmbH.



RECOMMENDATION

Notes with this symbol are recommendations of Murrelektronik GmbH.



Products and Accessories

This symbol refers to accessories or product recommendations.

Instruction for use

- ➔ An arrow marks instructions for use.
- ➔ Read and observe the instructions for use.
- 1 | If they are numbered, it is absolutely necessary to follow them in the correct order.
- 2 | Read and observe the instructions for use.

1.5 Trademarks

The trademarks of the following companies are used in this documentation:

Adobe Systems Corp.	Adobe Acrobat Reader
Microsoft Corp.	Microsoft Windows 7, Windows Vista, Windows 2000, Windows XE/XP and Microsoft Internet Explorer
PROFIBUS International (P.I.)	PROFIBUS, PROFIBUS DP
PROFIBUS / PROFINET International (P.I.)	PROFINET, PROFINET IO
ODVA Open DeviceNet Vendor Association	EtherNet/IP
Beckhoff Automation GmbH	EtherCAT
CAN in AUTOMATION - International Users and Manufacturers Group e.V.	CANopen
Gould Inc. Corporation	Modbus
Siemens AG	S5-200, S5-300, S5-400 S7-200, S7-300, S7-400

2 For your own safety

2.1 Target group

Users	This manual is intended for users who have knowledge of automation systems.
Documentation	Please give this manual to all employees involved in the following tasks: <ul style="list-style-type: none">■ Planning■ Installation■ Set-up■ Operation

2.2 Intended purpose

Designated use	The Cube20S system has been designed and manufactured for: <ul style="list-style-type: none">■ communication and process control■ general control and automation tasks■ industrial use■ operation under the ambient conditions specified under technical data■ installation in a switch cabinet
Foreseeable misuse	The device is not approved for being used: <ul style="list-style-type: none">■ in potentially explosive atmospheres (EX Zone)■ outside of switch cabinets.

2.3 General safety instructions

Note:

- the relevant safety and accident prevention regulations;
- the EC Directives or other national regulations;
- generally recognized safety rules;
- the section 2.5 "EMC installation guidelines".

NOTICE

Defective device!

Improper use of the hardware and software can cause damage to the device.

- ➔ Only qualified personnel of Murrelektronik GmbH may manipulate the device.
- ➔ Only use the device to the extent described in the manual.

Avoid accidents caused by electrical voltage!

- ➔ Comply with the 5 safety rules of electrical engineering!
- ➔ Disconnect the device from the mains.
- ➔ Then carry out installation or repair work.

Avoid personal and material damage due to malfunctions!

- ➔ Provide external circuit breakers.
- ➔ The device may only be operated within the specified tolerances.

Avoid undefined states!

- ➔ Select and install connection lines so that capacitive and inductive interferences do not have adverse effects on the system.
- ➔ Protect the device against improper and unintended use.

2.4 Notes on electrostatically sensitive equipment

NOTICE**Overvoltage due to electrostatic discharge!**

The assemblies might get damaged.

- ➔ Ensure sufficient grounding of persons and working material!

Handling

Murrelektronik assemblies include highly integrated MOS components. These components are extremely sensitive to over-voltages occurring, for example, due to electrostatic discharge. Assemblies at risk are marked by the adjacent symbol.

The symbol is fixed to assemblies, sub-racks or packaging and indicates electrostatically sensitive equipment. These assemblies may become irreparably damaged by voltage and energy levels which are far below the perception levels of human beings.

If a person who is not electrostatically discharged handles electrostatically sensitive equipment, voltages may be produced. They may damage components, impair the functioning of the assemblies or render the assembly inoperative. Frequently, assemblies damaged like this cannot directly be recognized as faulty. The fault may show only after longer operation.

Components damaged by electrostatic discharge may produce temporary faults in case of temperature changes, vibrations or load changes.

Only with a consistent use of protective devices and a responsible compliance of the instructions for use can you avoid malfunctions or failures of the electrostatically sensitive equipment.

Shipping

- ➔ For shipping electrostatically sensitive equipment, use **always** the original packaging.

Measurements

Observe the following notes for measurements on electrostatically sensitive equipment:

- ➔ Discharge potential-free measuring instrument briefly.
- ➔ Ground the measuring instruments used.

Modifications

Observe the following in case of modifications on electrostatically sensitive equipment:

- ➔ Use a grounded soldering iron.

2.5 EMC installation guidelines

Industrial use

The CUBE20S system is an electronic device manufactured according to the current state-of-the-art standards. Both the robust mechanical construction and the design of the electronic components make it ideal for industrial use.

To guarantee a trouble-free operation, observe the following rules when installing the device in systems. Otherwise, the high interference immunity and resistance to damage of the device may become partially ineffective.

The interference immunity of the entire system considerably depends on the correct installation, location and wiring.

- 1 | For safe operation, check the installation regulations stipulated by the manufacturer of the controller.
- 2 | Bring them in line with the recommendations for an EMC-compatible design.
- 3 | Then install CUBE20S system.

2.6 Notes on spare parts and accessories

Spare parts

- Only use the original spare parts or spare parts by other manufacturers expressly authorized by Murrelektronik GmbH.
- Check the function of the device after having replaced a component.

Accessories

- The use of accessories may alter the device function. Use only accessories authorized by Murrelektronik GmbH.
- Observe the enclosed instructions of the accessories when installing them.

2.7 Environmentally friendly disposal



Disposal

Do not throw electrical devices, batteries or accumulators in the domestic waste!

If you want to dispose of the product, it may be returned free of charge to Murrelektronik GmbH. This is also valid for original packaging and batteries or accumulators.

Return

- ➔ Label the product and the packaging with "**For disposal**".
- ➔ Pack the product.
- ➔ Send the package to:
Murrelektronik GmbH
Falkenstraße 3
D-71570 Oppenweiler

We ensure that it is disposed of according to the German legislation. Transport to the place of destination is at the expense of the last owner.

2.8 EC Declaration of Conformity



Murrelektronik GmbH herewith declares that the products and systems comply with the basic requirements and other relevant regulations of the following Directives:

- 2004/108/EC Electromagnetic compatibility
- 2011/65/EU RoHS

2.9 Warranty and liability

Warranty and liability claims

Warranty and liability claims shall be lost if

- the product is not used according to its designated use,
- damage is caused because the manual and the operating instructions have not been observed,
- the staff was/is not qualified.

3 System description

3.1 System

Overview

The Cube20S system is a modular automation system mounted on a 35 mm DIN rail. Using 2, 4 and 8-channel expansion modules, you may adapt this system perfectly to your automation tasks.

You do not need much wiring because the 24 V DC power supply is integrated in the backplane bus. Defective electronic modules can be replaced without having to replace the wiring.

Using power modules with different colors, you may define further voltage ranges for the 24 V DC power supply within the system or add 2 A to the electronic supply.





Fig. 3-1: Cube20S system

Components

The Cube20S system consists of the following components:

- Bus node
- Expansion modules
- Power modules
- Accessories

Bus node



Bus interface and power module of the bus node are incorporated in one housing. The bus interface is used to connect to a parent bus system.


Both bus interface and the electronics of the connected expansion modules are supplied with power over the power module.

There is another connection on the power module for the 24 V DC power supply of the connected expansion modules.

By installing up to 64 expansion modules on the bus node, they will be electrically connected, i.e.

- they are incorporated in the backplane bus,
- the electronic modules are supplied with power,
- each expansion module is connected to the 24 V DC power supply.

Bus cover




Each bus node has a cover to protect the contacts.


- ➔ Remove the cover on the bus node before installing CUBE20S modules.
- ➔ To protect the contacts, mount the bus cover on the outmost module.

Expansion modules

Each expansion module consists of a terminal and an electronic module.



Terminal module




The terminal module consists of the following functional elements:

- a sliding mechanism to fasten the electronic module,
- the backplane bus with power supply for the electronics,
- the connection to the 24 V DC power supply,
- the staircase-shaped terminal block for wiring,
- a safe locking system for fastening on a mounting rail.

This locking mechanism allows you to mount your Cube20S system outside the switch cabinet and fix the complete system later in the switch cabinet.


Electronic module



The functionality of an expansion module is defined over the electronic module.

- If the electronic module is defective, it can be replaced while wiring is kept.
- On its front, there are LEDs indicating the status.
- For an easier wiring, there are wiring diagrams on the front and side of each electronic module.

Power modules



Power modules provide the Cube20S system with power. The power modules are either integrated in the bus node or may be plugged between the expansion module.

Depending on the type of power module, groups of potential can be defined for the 24 V DC power supply, or the electronics supply may be extended by 2 A.

For a better recognition, the power modules have a different color than the expansion modules.

3.2 Dimensions

Dimensions of the bus node




Fig. 3-2: Dimensions of the bus node

Dimensions of the expansion module




Fig. 3-3: Dimensions of the expansion module

Dimensions of the electronic module




Fig. 3-4: Dimensions of the electronic module

3.3 Mounting



NOTE

You can mount the modules individually or as a whole block on the DIN rail. For block installation, please observe the following: **All** locking levers must be open.

3.3.1 General notes

The individual modules are mounted directly on a DIN rail. Electronics and power supply are connected over the backplane bus.

Conditions:

- Max. number of plug-in modules: 64
- Max. total current of the electronics supply: 3 A

A **power module sensor/actuator/bus art. no. 57131** extends the current for the electronics supply by 2 A. For details, refer to section 3.5 "Wiring".




Fig. 3-5: Installing the module

3.3.2 Functional principle of the locking

Inserting and locking the module

- ✖ The terminal module has a locking lever at its top.
- 1 | For installation and disassembly, please press this lever upwards until it engages audibly.
- 2 | Plug the module to be mounted in the previously plugged-in module.
- 3 | Slide the module with the help of the guide strips at top and bottom onto the DIN rail.
- 4 | Flap the locking lever downwards.

The module is fastened to the DIN rail.

3.3.3 Replacing an electronic module

Disassembly

- ✓ The electronic module has a locking lever at the bottom.
- 1 | Press the locking lever upwards for disassembly.
- 2 | To remove the electronic module, pull it out towards the front.

The electronic module has been removed.

Installation

- ✓ The electronic module has a locking lever at the bottom.
- ➔ Slide the electronic module with the help of the guide strip into the terminal module.

The electronic module engages audibly at the bottom.




Fig. 3-6: Disassembling and installing the electronic module

3.3.4 Installing the DIN rail

- ➔ Install the DIN rail with the necessary distances (see Fig. 3-7: "Installation distances").




Fig. 3-7: Installation distances

3.3.5 Installing the bus node

- ✓ To mount the system, start on the left with the bus node.
- 1 | Flap the two locking levers of the bus node upwards.
- 2 | Plug the bus node in the DIN rail.
- 3 | Flap the two locking levers of the bus node downwards.
- 4 | To remove the right bus cover, pull it out towards the front.
- 5 | Store the bus cover to use it as termination of the system.




Fig. 3-8: Installing the bus node

3.3.6 Installing the expansion modules

- 1 | Flap the locking lever of the expansion module upwards.
- 2 | Plug the expansion module in the DIN rail.
- 3 | Push the expansion module towards the bus node or the last expansion module.
- 4 | Flap the locking lever of the expansion module downwards.
- 5 | Mount all expansion modules as described.




Fig. 3-9: Installing the expansion module

3.3.7 Installing the bus cover

- ✓ Prerequisite: The system has been completely mounted.
- ➔ Plug the bus cover in the outmost module as a protection of the bus contacts.




Fig. 3-10: Installing the bus cover

3.4 Disassembling and replacing modules

3.4.1 Procedure

During disassembly or when replacing a module or module group, please observe the following:

- 1 | Remove the electronic module to the right of the module or module group.
- 2 | Dismount/replace the module or module group.
- 3 | Plug in the electronic module.

3.4.2 Replacing an electronic module

Disassembly

- ✓ The electronic module has a locking lever at the bottom.
- 1 | Press the locking lever upwards for disassembly.
- 2 | To remove the electronic module, pull it out towards the front.

The electronic module has been removed.

Installation

- ✓ The electronic module has a locking lever at the bottom.
- ➔ Slide the electronic module with the help of the guide strip into the terminal module.

The electronic module engages audibly at the bottom.




Fig. 3-11: Disassembling and installing the electronic module

3.4.3 Replacing a module

Dismounting

- 1 | Remove the wiring from the module, if any. For details refer to section **Wiring**.
- 2 | Unlock the electronic module to its right at the bottom.
- 3 | To remove the electronic module, pull it out towards the front.
- 4 | Flap the locking lever of the module to be replaced upwards.
- 5 | To remove the module, pull it out towards the front.




Fig. 3-12: Disassembling a module

Installing the new module

- 1 | Flap the locking lever of the module upwards.
- 2 | Plug the module in the gap between the modules.
- 3 | Slide the module with the help of the guide strips at both sides onto the DIN rail.
- 4 | Flap the locking lever of the module downwards.
- 5 | Plug in the electronic module.




Fig. 3-13: Installing the new module

3.4.4 Replacing a bus node

Disassembly

**CAUTION!**

Power module and bus interface belong together!

If separated, the modules get destroyed.

→ Do not separate power module and bus interface!

- 1 | Remove the wiring from the bus node, if any. For details, please see section **Wiring**.
- 2 | Unlock the electronic module to its right at the bottom.
- 3 | To remove the electronic module, pull it out towards the front.
- 4 | Flap the locking lever of the bus node upwards.
- 5 | To remove the bus node, pull it out towards the front.




Fig. 3-14: Disassembling the bus node

Installing the new bus node

- 1 | Flap the locking levers of the bus node upwards.
- 2 | Plug the bus node in the left module.
- 3 | Slide the bus node with the help of the guide strips onto the DIN rail.
- 4 | Flap the locking levers downwards.
- 5 | Plug in the electronic module.




Fig. 3-15: Installing the new bus node

3.4.5 Replacing a module group

Disassembly

- 1 | Remove the wiring from the module group, if any. For details, please see section **Wiring**.
- 2 | Unlock the electronic module to its right at the bottom.
- 3 | To remove the electronic module, pull it out towards the front.
- 4 | Flap the locking levers of the module group upwards.
- 5 | To remove the module group, pull it out towards the front.




Fig. 3-16: Disassembling the module group

Installing the new module group

- 1 | Flap the locking levers of the module group upwards.
- 2 | Plug the module group in the gap between the modules.
- 3 | Slide the module group with the help of the guide strips at both sides onto the DIN rail.
- 4 | Flap the locking levers of the module group downwards.
- 5 | Plug in the electronic module.




Fig. 3-17: Mounting of the module group


3.5 Wiring

3.5.1 Spring terminals

Terminals

Spring terminals are used for wiring. Spring terminals allow you to connect the signaling lines and power cables fast and easily. This type of connection is resistant to vibrations.


Cable data

	$U_{\max.}$: 240 V AC / 30 V DC
	$I_{\max.}$: 10 A
	Cross section: 0.08 ... 1.5 mm ² (AWG 28 ... 16)
	Stripping length: 10 mm

3.5.2 Procedure

Wiring

✂ Tools: suitable screwdriver



✂ Wire cross-section: 0.08 mm² ... 1.5 mm² (AWG 28 ... 16)

- 1 | Put the screwdriver slightly inclined in the rectangular opening (Fig. 3-18: 1).
- 2 | Press and hold the screwdriver away from the round opening. The contact spring is open (Fig. 3-18: 2).
- 3 | Put the stripped wire in the round opening (Fig. 3-18: 2).
- 4 | Remove the screwdriver (Fig. 3-18: 3).

The wire is securely connected with the terminal by means of a spring contact.




Fig. 3-18: Spring terminals

3.5.3 Standard wiring

Standard wiring




Fig. 3-19: Standard wiring

- 1 24 V DC for power supply of I/O level (max. 10 A)
- 2 24 V DC for electronics supply, bus node and I/O level

3.5.4 Fuse protection



WARNING!

The power supply is not protected internally.

It can get destroyed by too high currents.

→ Protect the power supply externally using a fuse or line circuit breaker!



NOTE

The electronics supply is internally protected against too high voltages by means of a fuse. The fuse is located inside the power module. After the fuse has tripped, the electronic module has to be replaced!

External fuse

	External Fuse	Circuit breaker (optional)	Comment
Power supply	10 A (fast)	10 A characteristic Z	up to max. current 10 A
Electronics supply, bus node and I/O level	2 A (fast)	2 A characteristic Z	Recommendation!
Electronics supply, I/O level, power module art. no. 57131	1 A (fast)	1 A characteristic Z	Recommendation!

Tab. 3-1: Fuse protection of power supplies

3.5.5 Using power modules

Status of the electronics power supply

After switching on Cube20S, the RUN or MF LED lights up at every module. If the total current for the electronics supply exceeds 3 A, the LEDs are not activated. In this case, plug in the power module, art. no. 57130, between the expansion modules.



NOTE

To guarantee power supply, the power modules can be used in any combination.

Power module art. no. 57130

Use this power module if

- 10 A are not longer enough for power supply
- you want to have groups of different potentials




Fig. 3-20: Power module art. no. 57130

- 1 24 V DC for power supply of I/O level (max. 10 A)
- 2 24 V DC for electronics supply, bus node and I/O level

**Power module art. no.
57131**

Use this power module if 3 A are not enough for electronics supply on backplane bus.

In addition, you will have a new group of potential for 24 V DC power supply with max. 4 A.

Using a power module, you can plug in modules with a maximum total current of 2 A in the following backplane bus. Then you have to plug in another power module.




Fig. 3-21: Power module art. no. 57131

- 1 24 V DC for power supply of I/O level (max. 10 A)
- 2 24 V DC for electronics supply, bus node and I/O level
- 3 24 V DC for power supply of I/O level (max. 4 A)
- 4 24 V DC for electronics supply, I/O level

3.5.6 Fixing the shield



Fixing the shield

NOTE

Shield bus carriers are required for installing a shield (see **Accessories**).




Fig. 3-22: Fixing the shield

- 1 Shield bus carrier
- 2 Shield bus (10 mm x 3 mm)
- 3 Shield terminal block
- 4 Shielding







Fixing the shielding

- ✓ The shield bus carrier and the shield bus have been plugged in.
- ➔ Fasten the lines with the stripped shield.
- ➔ Connect the shield terminal blocks to the shield bus.

3.6 Troubleshooting - LEDs


General information

Each module has two LEDs on the front: **RUN** and **MF**. These LEDs allow you to detect errors in your system or faulty modules.

Designation	Indication	LED status
RUN LED		off
		green
		flashing green
MF LED		off
		red
		flashing red


Tab. 3-2: Status indications of the LEDs

Total current of electronics supply exceeded




Reaction of the LEDs after switching on:	The RUN LEDs of all modules are off. The MF LEDs are only lighted on some modules.
Cause:	The total current for electronics supply exceeds the maximum current.
Remedy:	Plug in the power module art. no. 57131. For details, please see section Wiring .

Configuration error



Reaction of the LEDs after switching on:	The RUN LEDs are off on one or several modules. The MF LEDs are flashing on these modules.
Cause:	The module on which the MF LED is flashing, does not match the current configuration.
Remedy:	Match configuration and hardware structure.

Module failure



Reaction of the LEDs after switching on:	The RUN LEDs are flashing up to the module to the left of the defective module. On the following modules, the RUN LED is off. The MF LEDs are off up to the module to the left of the defective module. On the following modules, the MF LED is lit.
Cause:	The module to the right of the flashing modules is defective.
Remedy:	Replace the defective module.

4 Art. no. 57140 Communication module RS232


4.1 Features

Features


- Serial RS232 interface (electrically isolated from the backplane bus)
- Data transfer rate of 150 bit/s up to maximum 115.2 kbit/s
- Serial communication via RS232
- Protocols
 - ASCII
 - STX/ETX
 - 3964(R)
 - Modbus (master/slave with ASCII and RTU short & long) with a telegram length of 250 bytes
- Up to 250 telegrams (1024 bytes of receive and send buffer)
- Character delay time can be parameterized in ms steps
- Parameterization over 17 bytes of parameter data
- Modem signal management DTR-DSR-DCD

4.2 Design











57140





Status indication



RUN		off
		on
		Flashing with 2 Hz
MF		off
		on
		Flashing with 2 Hz
TxD		on
RxD		on
IF		Flashing with 2 Hz

RUN	MF	Description
		Bus communication is OK Module status is OK
		Bus communication is OK Module status reports error
		Bus communication is not possible Module status reports error
		Error Bus supply voltage
		Configuration error (see 3.6 Troubleshooting - LEDs, Seite 32)


Tab. 4-1: Status indications of RUN and MF LED

LED	Color	Description
TxD		Transmit data
RxD		Receive data
IF		Modbus: internal error Other protocols: power interruption, overflow, parity error or character frame error

Tab. 4-2: Status indication of the LEDs TxD, RxD, IF

Terminal

➔ Connect the wires with a cross section from 0.08 mm² to 1.5 mm².



Pos.	Function	Type	Description
1	TxD	Output	Transmit data
2	RTS	Output	Request to send RTS at 1: Communication processor is ready to transmit RTS at 0: Communication processor is not transmitting
3	DCD	Input	Data carrier detect Data can be received
4	DSR	Input	Data set ready Modem indicates readiness for operation
5	RxD	Input	Receive data
6	CTS	Input	Clear to send Communication processor may send data
7	GND_ISO	Output	Zero reference point of signal (isolated)
8	DTR	Output	Data Terminal Ready Communication processor is ready for operation

Tab. 4-3: Terminal assignment



RS232 Interface

NOTE

RI (Ring indicator) - The communication processor does not use the ring tone RI of the modem!

- Logical states as voltage levels
- Point-to-point link with serial full-duplex transmission
- Data transfer to a distance of up to 15 m
- Data transfer rate up to 115.2 kbit/s

RS232
Wiring without
hardware
handshake




Fig. 4-1: RS232 wiring without hardware handshake


RS232
Wiring with
hardware
handshake

Fig. 4-2: RS232 wiring with hardware handshake

4.3 Quick start

Overview

The communication processor links serial processes at different target or source systems. While doing so, the communication processor is operated as an expansion module and supplied with operating voltage via the backplane bus.

Parameters

For parameterization, transfer the parameter data to the communication processor. They are assigned according to the selected protocol.

More detailed information on the assignment of the parameters is given in section 5 Serial communication protocols, Seite 61.

Protocols

The communication processor supports the following protocols:

- ASCII
- STX/ETX
- 3964(R)
- Modbus (master, slave)

Communication

Transmitting

- 1 | The parent system writes the data via the backplane bus to the output range.
- 2 | The communication processor writes the data to the send buffer.
- 3 | The communication processor outputs the data from the send buffer via interface.

Receiving

- 1 | The communication processor receives data via the interface.
- 2 | The communication processor saves the data in a circular buffer.
- 3 | The communication processor enters the data in the input range of the parent system via the backplane bus.



The size of the input/output range and, thus, the size of the telegram on the backplane bus depends on the parent system.

The input/output range (I/O range) and communication via the backplane bus are described in sections 4.4 and 4.5.




Fig. 4-3: Communication

4.4 Input/output range

Overview

Depending on the parent system, the communication processor assigns the following number of bytes in the address range for the input and output respectively:

System	Address range [byte]
PROFIBUS	8, 20, 60 (can be selected)
PROFINET	20, 60 (can be selected)
CANopen	8
EtherCAT	60
DeviceNET	60
ModbusTCP	60

Tab. 4-4: Overview of the address range

In CPU, PROFIBUS and PROFINET the input or output range is displayed in the corresponding address range with $n = 8, 20$ or 60 .

IX = Index for access using CANopen

Use s = subindex to address the corresponding byte

SX = Subindex for access via EtherCAT

Input range

Addr.	Name	Bytes	Function	IX = 0x5450	SX
+0	CP_IN_STS	1	Status byte	s = 1	0x01
+1	CP_IN_1	1	Input byte 1	s = 2	0x02
+2	CP_IN_2	1	Input byte 2	s = 3	0x03
...
+n-1	CP_IN_n-1	1	Input byte n-1	s = m	0xm

Tab. 4-5: Input range

CP_IN_STS

This parameter contains information on the fragmentation of the data in the receive buffer.

CP_IN_x

The contents of this data depends on the structure of the data in the receive buffer. Further information on this topic can be found on the following pages.

Output range

Addr.	Name	Bytes	Function	IX = 0x5650	SX
+0	CP_OUT_STS	1	Control byte	s = 1	0x01
+1	CP_OUT_1	1	Output byte 1	s = 2	0x02
+2	CP_OUT_2	1	Output byte 2	s = 3	0x03
...
+n-1	CP_OUT_n-1	1	Output byte n-1	s = m	0xm

Tab. 4-6: Output range

CP_OUT_CTRL

Here you can control the data transfer by means of the corresponding commands.

CP_OUT_x

The contents of this data depends on the structure of the data in the send buffer. Further information on this topic can be found on the following pages.


4.5 Principle of the backplane bus communication

4.5.1 Transmitting data

Overview

- The parent system enters the data to be output into the output range and transfers them with the **control byte** to the communication processor.
- The communication processor acknowledges each telegram:
 - it copies bit 3 ... 0 from byte 0 of the output range to bit 7 ... 4 of byte 0 of the input range **or**
 - it uses this byte to send back a corresponding **status message**.
- Depending on the length of the data to be transferred, the telegram is transmitted to the communication processor in one or several fragments.
- In case of fragmented transmission, the communication processor acknowledges each fragment.

Principle of transmission without fragmentation



with n = number of the assigned bytes in the address range (IO size)

Control byte

Bit	Hex	Function
3 ... 0	0x08	Idle run - no data available
	0x0A	Start transmission without fragmentation
	0x0B	Perform a reset of the communication processor
7 ... 4		Reserved for receiving

Tab. 4-7: Control byte

Telegram info byte

During transmission 0x00 (fixedly).

Length

Length of the payload for the serial communication in bytes.

Payload byte

The byte contains the payload for the serial communication.

Acknowledgement / status

Bit	Hex	Function	
3 ... 0		Reserved for receiving	
7 ... 4	0x08	Acknowledgement	Idle run
	0x0A		Receiving data without fragmentation
	0x0C	Status	Reset of communication processor performed
	0x0D		The specified length is not valid
	0x0E		Error in the communication of the communication processor - partner does not respond

Tab. 4-8: Acknowledgement / status

Principle of transmission with fragmentation

- The parent system transmits the amount of payload and part of the payload in the 1st telegram.
- After that the parent system transmits the fragment telegrams.
- The communication processor acknowledges each fragment telegram:
 - it copies bit 3 ... 0 from byte 0 of the output range to bit 7 ... 4 of byte 0 of the input range **or**
 - it uses this byte to send back a corresponding **status message**.


Procedure

- 1 | Write the 1st telegram
- 2 | Write fragments
- 3 | Write last fragment

Calculation of the number of fragments

$$\text{Number of fragments} = (\text{length} + 3) / (\text{IO_Size} - 1)$$

Write the 1st telegram (header)



with n = number of the assigned bytes in the address range (IO size)

Control byte

Bit	Hex	Function
3 ... 0	0x08	Idle run - no data available
	0x09	Start fragmented transmission
	0x0A	Transmit the last fragment
	0x0B	Run a reset of the communication processor
7 ... 4		Reserved for receiving

Tab. 4-9: Control byte

Telegram info byte

During transmission 0x00 (fixedly).

Length

Length of the payload for the serial communication in bytes.

Payload byte


The byte contains the payload for the serial communication.

Acknowledgement / status

Bit	Hex	Function	
3 ... 0		Reserved for receiving.	
7 ... 4	0x08	Acknowledgement	Idle run
	0x09		Fragmented transmission started
	0x0A		Receiving data without fragmentation
	0x0C	Status	Reset of communication processor performed
	0x0D		The specified length is not valid
	0x0E		Error in communication of the communication processor - partner does not respond

Tab. 4-10: Acknowledgement / status

Writing the fragments



with n = number of the assigned bytes in the address range (IO size)

Control byte

Bit	Hex	Function
3 ... 0	0x00	Fragment number
	...	
	0x07	
	0x08	Idle run - no data available
7 ... 4	0x0B	Run a reset of the communication processor
		Reserved for receiving

Tab. 4-11: Control byte

Payload byte


The byte contains the payload for the serial communication.

Acknowledgement / status

Bit	Hex	Function	
3 ... 0		Reserved for receiving	
7 ... 4	0x00	Acknowledgement	Fragment number
	...		
	0x07		
	0x08		Idle run
	0x0C	Status	Reset of communication processor performed
	0x0D		The specified length is not valid
0x0E	Error in the communication of the communication processor - partner does not respond		

Tab. 4-12: Acknowledgement / status

Writing the last fragment



with n = number of the assigned bytes in the address range (IO size)

Control byte

Bit	Hex	Function
3 ... 0	0x08	Idle run - no data available
	0x0A	Transmit the last fragment
	0x0B	Run a reset of the communication processor
7 ... 4		Reserved for receiving

Tab. 4-13: Control byte

Payload byte

The byte contains the payload for the serial communication.

Acknowledgement / status

Bit	Hex	Function	
3 ... 0		Reserved for receiving.	
7 ... 4	0x08	Acknowledgement	Idle run
	0x0A		Last fragment received
	0x0C	Status	Reset of communication processor performed
	0x0D		The specified length is not valid
	0x0E		Error in the communication of the communication processor - partner does not respond

Tab. 4-14: Acknowledgement / status

4.5.2 Receiving data

Overview

- The communication processor enters the received data automatically in the input range of the parent system.
- Depending on the length of the received data, the communication processor transmits the telegram to the parent system:
 - in one fragment **or**
 - in several fragments.
- The fragmented transmission starts after bit 3 ... 0 from byte 0 of the input range to bit 7 ... 4 of byte 0 of the output range.
- The communication processor saves transmission errors in **RetVal**.

Principle of the transmission without fragmentation

Parent system		Communication processor	
Byte	Function	Byte	Function
		0	Info byte
		1	Telegram info byte
		2	Length high byte
		3	Length low byte
		[4]	Offset high byte
		[5]	Offset low byte
		6	RetVal high byte
		7	RetVal low byte
		8...n-1	Payload
0	Acknowledgement	0	

with n = number of the assigned bytes in the address range (IO size)

Info byte

Bit	Hex	Function
3 ... 0	0x08	Idle run - no data available
	0x09	Data are transmitted in fragments
	0x0A	Data are transmitted without fragmentation
7 ... 4		Reserved for transmitting

Tab. 4-15: Info byte

Telegram info byte

Hex	Function
0x00	The telegram does not contain any additional offset information.
0x04	The telegram contains additional offset information which is placed as a word after the length . The offset information determines the position of the payload in the input range.

Tab. 4-16: Telegram info byte

Length

Length of the payload for the serial communication in bytes plus 2 bytes for *RetVal*.

Offset If the **telegram info byte** has the value 0x04, an offset is entered additionally. Otherwise, there is no **offset** in the telegram.

RetVal

Hex	Function
0x0517	Invalid length (length = 0 or length >1024)
0x080A	No free receive buffer available
0x080C	Incorrect character received (character frame or parity error)

Tab. 4-17: RetVal


Payload Contains the received payload of the serial communication.

Acknowledgement After the parent system has processed the data, it has to acknowledge the receipt to the communication processor. Only after that the communication processor provides new receive data.

Bit	Hex	Function
3 ... 0		Reserved for transmitting
7 ... 4	0x08	Acknowledgement
	0x0A	Idle run
	0x0B	Input range free for new data
	0x0B	Command
		Perform a reset of the communication processor

Tab. 4-18: Acknowledgement

Principle of transmission with fragmentation



with n = number of the assigned bytes in the address range (IO size)

After the parent system has processed the data, it has to acknowledge the receipt to the communication processor.

For this purpose, it copies bit 3 ... 0 from byte 0 of the input range to bit 7 ... 4 from byte 0 of the output range. Only after that the communication processor provides new receive data.

Calculation of the number of fragments

Number of fragments = (length + 7) / (IO_Size-1)

Info byte

Bit	Hex	Function
3 ... 0	0x08	Idle run - no data available
	0x09	Data are transmitted in fragments
	0x0A	Data are transmitted without fragmentation
7 ... 4		Reserved for transmitting

Tab. 4-19: Info byte

Telegram info byte

Hex	Function
0x00	The telegram does not contain any additional offset information.
0x04	The telegram contains additional offset information which is placed as a word after the length . The offset information determines the position of the payload in the input range.

Tab. 4-20: Telegram info byte

Length

Length of payload in bytes plus 2 bytes for **RetVal**.

Offset

If the **telegram info byte** has the value 0x04, an offset is entered additionally. Otherwise, there is no **offset** in the telegram.

Calculation of the offset in case of fragmented transmission:

$$\text{Data_offset} = (\text{fragment counter} + 1) \times (\text{IO_SIZE} - 1) - 7 + \text{offset}$$

with Data_offset: Offset of the data in the input range
 Fragment counter: Absolute number of fragments
 IO_Size: Number of the assigned bytes in the address range
 Offset: Offset value in the telegram

Payload

Contains the received payload of the serial communication.

Acknowledgement

After the parent system has processed the data, it has to acknowledge the receipt to the communication processor. Only after that the communication processor provides new receive data.

Bit	Hex	Function
3 ... 0		Reserved for transmitting
7 ... 4	0x08	Acknowledgement
	0x0A	Idle run
	0x0B	Input range free for new data
	0x0B	Command
		Perform a reset of the communication processor

Tab. 4-21: Acknowledgement

4.5.3 Examples

Transmitting data
without fragmentation

IO size = 60 bytes, length = 40 bytes

Parent system	
Byte	Function
0	0x0A command
1	0x00 telegram info
2	0x00 length high byte
3	0x28 length low byte
4 ... 43	Payload byte 0 ... 39
44 ... 59	not used

Communication processor	
Byte	Function
0	0xA0 acknowledge- ment

Transmitting data
with fragmentation

IO size = 16 bytes, length = 40 bytes

Header

Parent system	
Byte	Function
0	0x09 command
1	0x00 telegram info
2	0x00 length high byte
3	0x28 length low byte
4 ... 15	Payload byte 0 ... 11

Communication processor	
Byte	Function
0	0x90 Acknowledge- ment

1st fragment

Parent system			
Byte	Function	Byte	Function
0	0x00 fragment		
1 ... 15	Payload byte 12 ... 26		
		0	0x00 Acknowledgement

2nd fragment

Parent system			
Byte	Function	Byte	Function
0	0x01 fragment		
1 ... 15	Payload byte 27 ... 41		
		0	0x10 Acknowledgement

Last fragment

Parent system			
Byte	Function	Byte	Function
0	0x0A command		
1 ... 8	Payload byte 42 ... 49		
11 ... 15	not used		
		0	0xA0 acknowledgement

Receiving data
 without fragmentation

IO size = 60 bytes, length = 40 bytes

Parent system	
Byte	Function
0	0xA0 acknowl- edgement



Communication processor	
Byte	Function
0	0x0A fragment info
1	0x00 telegram info byte
2	0x00 length high byte
3	0x2A length low byte + 2 bytes
4	0x00 return value high byte
5	0x00 return value low byte
6 ... 45	Payload byte 0 ... 39
46 ... 59	is not used
0	

Receiving data
 with fragmentation

IO size = 16 bytes, length = 40 bytes

Header

Parent system	
Byte	Function
0	0x90 Acknowl- edgement



Communication processor	
Byte	Function
0	0x09 fragment info
1	0x00 telegram info byte
2	0x00 length high byte
3	0x2A length low byte + 2 bytes
4	0x00 return value high byte
5	0x00 return value low byte
6 ... 15	Payload byte 0 ... 9
0	

1st fragment

Parent system	
Byte	Function
0	0x00 Acknowledgement



Communication processor	
Byte	Function
0	0x00 fragment info
1 ... 15	Payload byte 10 ... 24
0	

Last fragment

Parent system	
Byte	Function
0	0xA0 acknowledgement



Communication processor	
Byte	Function
0	0x0A fragment info
1 ... 15	Payload byte 25 ... 39
0	

4.6 Backplane bus communication

Overview

To process connection jobs on the PLC side, a user program is necessary in the CPU. For this purpose the following specific blocks by Murrelektronik GmbH are used for communication between CPU, communication processor and a communication partner:

Block	Icon	Comment
FB 60	SEND	Block for data transmission to a communication partner
FB 61	RECEIVE	Block for receiving data from a communication partner

Tab. 4-22: Blocks for transmitting and receiving

4.6.1 Installing blocks

Installing blocks

The specific blocks by Murrelektronik GmbH can be found in the Service area on www.murrelektronik.com under Downloads > ME LIB in form of a library for download.

The library is available as a packed zip file. It must be imported into your project.

The following steps are necessary for this:

- Unpack file FX000011_Vxxx.zip
- Retrieve **library**
- Open the library and transfer blocks to project

FX000011_Vxxx.zip

Unpacking FX000011_Vxxx.zip

- ➔ Start your unzip tool by double-clicking **FX000011_Vxxx.zip**.
- ➔ Copy the Murrelektronik.ZIP file to your working directory.

It is not necessary to continue unpacking this file.

Retrieving the library

Retrieve the library for the SPEED7 CPUs.

- ➔ Start the SIMATIC Manager by Siemens.
- ➔ Go to **File > Retrieve** to open a dialog window and select the archive.
- ➔ Browse to your working directory.
- ➔ Click Murrelektronik.ZIP.
- ➔ Click **Open**.
- ➔ Specify a target directory where the block has to be saved.
- ➔ Click **OK**.

The unpacking process starts.

Opening the library and transferring blocks to the project

Opening the library

- ➔ Open the library after unpacking.
- ➔ Open your project.
- ➔ Copy the required blocks from the library into the **Blocks** directory of your project.

In your user program, you have access to the specific blocks by Murrelektronik GmbH.

Communication principle

The communication processor calls FB 60 and FB 61 cyclically and receives the data cyclically. The communication processor implements the transmission protocols for the communication partner. The transmission protocols can be parameterized in the hardware configuration.

Sending telegram	The CPU divides a telegram depending on the IO size in blocks and transfers it via the data channel to the communication processor. The communication processor combines the blocks in the send buffer and sends the entire telegram using the serial interface.
Receiving telegram	<p>An entire telegram is divided into data blocks depending on the parameterized IO size and then transmitted to the backplane bus. The CPU combines the data blocks.</p> <p>The communication processor receives the telegrams from the CPU asynchronously via the backplane bus.</p> <p>If an entire telegram has been received via the serial interface, it is saved in a circular buffer (size of the circular buffer: 1024 bytes). The length of still available circular buffer gives the max. length of a telegram. Depending on the parameterization, up to 250 telegrams can be buffered, whose total length, however, may not exceed 1024 bytes. If the buffer is full, new telegrams are rejected.</p>
Software handshake	Since the data exchange via backplane bus runs asynchronously, a software handshake between the communication processor and the CPU is used. For this purpose, the blocks FB 60 and FB 61 have a common parameter CONTROL . Both blocks use for CONTROL different bits in the same flag byte.




Fig. 4-4: Communication processor CPU-57140

**NOTE**

A minimum pulse duration is required to detect a signal change. The decisive factors are:

- ➔ CPU cycle time,
- ➔ Refresh time on the communication processor,
- ➔ Reaction time of the communication partner.

4.6.2 FB 60 - SEND**FB 60 - SEND**
Transmitting to the communication processor

The FB 60 block outputs the data from the CPU to the communication processor. Use the identifiers **DB_NO**, **DBB_NO** and **LEN** to specify the transmission range. A positive edge at **REQ** triggers the data transmission.

Parameters

Name	Declaration	Type	Description
REQ	IN	BOOL	Transmission release at positive edge
R	IN	BOOL	Triggers synchronous reset.
LADDR	IN	INT	Logical base address of the communication processor
DB_NO	IN	INT	Number of the data block of transmit data
DBB_NO	IN	INT	Number of the data byte - transmit data starting from data byte
LEN	IN	INT	Length of the send telegram in bytes
IO_SIZE	IN	WORD	Parameterized IO size of the module
DONE *	OUT	BOOL	Send job completed without errors
ERROR *	OUT	BOOL	Send job completed with errors STATUS contains the error information
STATUS *	OUT	WORD	Specification of the error if ERROR = 1
CONTROL	IN_OUT	BYTE	Divided byte with RECEIVE block: SEND (bit 0 ... 3) RECEIVE (bit 4 ... 7)

Tab. 4-23: Parameters

* The parameter is available until the next call by FB 60.



REQ

Request - Transmission release

A positive edge at the **REQ** input triggers the data transmission. Depending on the data volume, data transfer may continue over several program cycles.

R

Synchronous reset

Initialization

Call SEND in the start-up OB once with all parameters and set **R**.

Termination

Termination of the current job anytime with the signal state **1** at **R**.

FB is reset to the initial state.

NOTE

Data which have already been received by the communication processor are still being sent to the communication partner.

Transmitting switched off

Static signal state **1** at **R**.

LADDR

Peripheral address

Use **LADDR** to enter the address of the communication processor to be addressed. It is the address which you have assigned to the communication processor in the hardware configuration.

DB_NO

Data block number

Number of the data block which contains the data to be transmitted. Zero is not allowed.

DBB_NO	Data byte number Number of the data byte in the data block starting from which the transmit data are saved.
LEN	Length Length of the payload to be transmitted. The following applies: $1 \leq \text{LEN} \leq 1024$.
IO_SIZE	Size I/O range Enter the size of the I/O range here. Depending on the parent system, the communication processor assigns the following optionally selectable number of bytes in the address range for the input and output respectively:

System	Address range [byte]
PROFIBUS	8, 20, 60 (can be selected)
PROFINET	20, 60 (can be selected)
CANopen	8
EtherCAT	60
DeviceNET	60
ModbusTCP	60

Tab. 4-24: IO_SIZE: Size I/O range

DONE	Job done without errors DONE is set if the job has been completed without errors and STATUS = 0x0000.
ERROR	Job done with errors ERROR is set. STATUS contains the error information.
STATUS	In case of error-free function, STATUS is 0x0000. As long as ERROR is set, the value in STATUS remains unchanged.

Error code	Function
0x0000	No error available
0x0202	FB 60 block and communication processor are not synchronous (Remedy: Trigger synchronous reset)
0x0301	DB is not valid
0x070A	Transmission failed, partner does not respond or has acknowledged the job negatively
0x0816	Invalid LEN parameter (LEN = 0 or LEN > 1024)
0x8181	Job running (status and no error message)

Tab. 4-25: Error messages

CONTROL	The SEND and RECEIVE blocks use the common CONTROL parameter for the handshake. ➔ Assign a common flag byte to the CONTROL .
Error indication	The DONE output indicates Job completed without errors , the value of STATUS is 0. For ERROR , the event number is displayed in STATUS . DONE , ERROR and STATUS are also output in case of reset of the block. In case of an error, the binary result BIE is reset. If the block is completed without errors, BIE has the state 1.



The parameters **DONE**, **ERROR** and **STATUS** are always available only for one call of the block.

➔ Copy **DONE**, **ERROR** and **STATUS** for further evaluation into a free data range.

4.6.3 FB 61 - RECEIVE

FB 61 - RECEIVE Receiving from communication processor

The FB 61 block supports data receiving of the CPU from the communication processor. Use the identifiers **DB_NO**, **DBB_NO** and **LEN** to specify the receiving range. The length of read-in telegrams is saved in **LEN**.

Parameters

Name	Declaration	Type	Description
EN_R	IN	BOOL	Release for reading of data
R	IN	BOOL	Triggers synchronous reset.
LADDR	IN	INT	Logical base address of the communication processor
DB_NO	IN	INT	Number of the data block of transmit data
DBB_NO	IN	INT	Number of the data byte - receive data starting from data byte
IO_SIZE	IN	WORD	Configured IO size of the module
LEN	IN	INT	Length of the send telegram in bytes
NDR *	OUT	BOOL	Receive job done without errors
ERROR *	OUT	BOOL	Receive job done with errors STATUS contains the error information
STATUS *	OUT	WORD	Specification of the error if ERROR = 1
CONTROL	IN_OUT	BYTE	Divided byte with SEND block: SEND (bit 0 ... 3) RECEIVE (bit 4 ... 7)

Tab. 4-26: Parameters

* The parameter is available until the next call by FB 61.



EN_R

Enable Receive - Enable reading

Signal state **1** at EN_R enables the check aiming at finding out whether there are data from the communication processor to be read. Depending on the data volume, data transfer may continue over several program cycles.

The signal state **0** at EN_R can be used to cancel the running transmission. The canceled receive job is completed with an error message (**STATUS**). As long as **0** is active at EN_R, receiving is switched off.

R

Synchronous reset

Initialization	Call RECEIVE in the start-up OB once with all parameters and set R .
Termination	Termination of the current job anytime with the signal state 1 at R . FB is reset to the initial state.
Receiving disabled	Static signal state 1 at R .

LADDR

Peripheral address

Use **LADDR** to enter the address of the communication processor to be addressed. It is the address which you have assigned to the communication processor in the hardware configuration.

DB_NO

Data block number

Number of the data block which contains the data to be transmitted. Zero is not allowed.

DBB_NO	Data byte number Number of the data byte in the data block starting from which the received data should be saved.
LEN	Length Length of the payload to be transmitted. The following applies: $1 \leq \text{LEN} \leq 1024$.
IO_SIZE	Size I/O range Enter the size of the I/O range here. Depending on the parent system, the communication processor assigns the following optionally selectable number of bytes in the address range for the input and output respectively:

System	Address range [byte]
PROFIBUS	8, 20, 60 (can be selected)
PROFINET	20, 60 (can be selected)
CANopen	8
EtherCAT	60
DeviceNET	60
ModbusTCP	60

Tab. 4-27: IO_SIZE: Size I/O range

NDR	New data ready New data are ready for the CPU in the communication processor.
ERROR	Job done with errors ERROR is set. STATUS contains the error information.
STATUS	In case of error-free function, STATUS is 0x0000. As long as ERROR is set, the value in STATUS remains unchanged.

Error code	Function
0x0000	No error available
0x0202	Block and communication processor are not synchronous (Remedy: Trigger synchronous reset)
0x0301	DB is not valid
0x070A	Transmission failed, partner does not respond or has acknowledged the job negatively
0x0816	Invalid LEN parameter (LEN = 0 or LEN > 1024)
0x080A	No free receive buffer is available
0x080C	Incorrect character received (character frame or parity error)
0x8181	Job running (status and no error message)

Tab. 4-28: Error messages

CONTROL	The SEND and RECEIVE blocks use the common CONTROL parameter for the handshake. ➔ Assign a common flag byte to the CONTROL .
---------	---

Error indication

The **NDR** output indicates **Job done without errors / Data adopted**. For **ERROR**, the corresponding event number is displayed in **STATUS**. If no error has occurred, the value of **STATUS** is **0**. NDR and **ERROR/STATUS** are also output in case of reset of FB. If an error has occurred, the binary result **BIE** is reset. If the block is completed without errors, **BIE** has the state **1**.



The parameters NDR, ERROR and STATUS are always available only for the calling of block.

➔ Copy these parameters for further evaluation into a free data range.

4.7 Diagnostic data

Overview

Using parameterization you can enable a diagnostic interrupt for the module.

- Upon triggering of a diagnostic interrupt, the module provides t_{incoming} diagnostic data for diagnostics.
- As soon as the reasons for the triggering of a diagnostic interrupt are not present anymore, you receive automatically an t_{outgoing} diagnostic interrupt.
- During this period of time (t_{incoming} 1st diagnostic interrupt until the last diagnostic interrupt t_{outgoing}) the MF-LED of the module is lit.

- DS Data record for access using CPU, PROFIBUS and PROFINET
 Access using DS 0x01
 Additional access to the first 4 bytes using DS 0x00
- IX Index for access using CANopen
 Access using IX 0x2F01.
 Additional access to the first 4 bytes using IX 0x2F00
- SX Subindex for access via EtherCAT

Name	Bytes	Function	Default	DS	IX	SX
ERR_A	1	Diagnostics	0x00	0x01	0x2F01	0x02
MODTYP	1	Module information	0x10			0x03
ERR_C	1	reserved	0x00			0x04
ERR_D	1	Diagnostics	0x00			0x05
CHTYP	1	Channel type	0x60			0x06
NUMBIT	1	No. of diagnostic bits per channel	0x08			0x07
NUMCH	1	Number of channels of the module	0x01			0x08
CHERR	1	reserved	0x00			0x09
CH0ERR	1	reserved	0x00			0x0A
CH1ERR ... CH7ERR	7	reserved	0x00			0x0B ... 0x11
DIAG_US	4	μ s ticker	0x00			0x12

Tab. 4-29: Diagnostic data

ERR_A Diagnostics

Byte	Bit 7 ... 0	Description
0	0	set in case of Assembly fault
	1	set in case of Internal error
	2	reserved
	3	reserved
	4	set in case of Missing external power supply
	5, 6	reserved
	7	set in case of Parameter error

Tab. 4-30: Diagnostics

MODTYP Module information

Byte	Bit 7 ... 0	Description
0	Bit 3 ... 0	Module class
		1111b Communication processor
	Bit 4	set if Channel information available
	Bit 7 ... 5	reserved

Tab. 4-31: Module information

ERR_D
 Diagnosis

Byte	Bit 7 ... 0	Description
0	Bit 2 ... 0	reserved
	Bit 3	set in case of Internal diagnosis buffer overflow
	Bit 4	set in case of Internal communication error
	Bit 7 ... 5	reserved

Tab. 4-32: Diagnosis

 CHTYP
 Channel type

Byte	Bit 7 ... 0	Description
0	6 ... 0	Channel type
		0x60 Communication processor
	7	reserved

Tab. 4-33: Channel type

 NUMBIT
 Diagnostic bits

Byte	Bit 7 ... 0	Description
0	7 ... 0	Number of diagnostic bits of the module per channel (here 0x08)

Tab. 4-34: Diagnostic bits

 NUMCH
 Channels

Byte	Bit 7 ... 0	Description
0	7 ... 0	Number of channels of a module (here 0x01)

Tab. 4-35: Channels

 CHERR, CH0ERR ...
 CH7ERRreserved

Byte	Bit 7 ... 0	Description
0	7 ... 0	reserved

Tab. 4-36: CHERR, CH0ERR ... CH7ERR

 DIAG_US
 µs ticker

Byte	Bit 7 ... 0	Description
0 ... 3	7 ... 0	Value of the µs ticker when generating diagnostic data

Tab. 4-37: µs ticker



µs ticker

There is a timer (µs ticker) in the module, it is started by means of PowerON and starts counting from 0 after $2^{32}-1$ µs.

5 Serial communication protocols

5.1 Overview

Serial transmission of a character

The point-to-point connection between two communication partners is the simplest form of information exchange. For this procedure, the communication processor acts as the interface between a parent system and a communication partner with serial connection.

The data are transmitted serially. During serial data transmission, the individual bits of a byte of the information to be transmitted are transmitted in a defined sequence.

Character frame

During the bidirectional data traffic, a distinction is made between **half-duplex** and **full-duplex** mode. In the **half-duplex** mode the data are either transmitted or received at a time. A simultaneous data exchange can only happen in the **full-duplex** mode.

Each character to be transmitted is preceded by a synchronizing pulse acting as a **start bit**. The end of the character transfer is formed by the **stop bit**.

Beside **start bit** and **stop bit**, further programmable agreements are necessary for a serial data transmission between the communication partners. This character frame consists of the following elements:

- Transfer rate (baud rate)
- Character and acknowledgement delay time
- Parity
- Number of data bits
- Number of stop bits

Protocols

The communication processor performs serial data transmission independently. For this purpose, the communication processor is equipped with drivers for the protocols.

The following protocols are described below:

- ASCII
- STEX/ETX
- 3964(R)
- Modbus (master, slave)

5.2 ASCII

5.2.1 Function

Mode of operation

The data communication via ASCII is a simple form of the data exchange. It can be compared with a multicast/broadcast function.

The **character delay time** (ZVZ) is used to separate the telegrams logically. During the character delay time, the transmitter must send its telegram to the receiver. A telegram is forwarded to the parent system only if it has been received completely.

As long as the **Time delay after command** (ZNA) has not elapsed, no new send job is accepted.

With these two time indications, a simple serial communication can be established.

Since no further measures for data back-up are taken for the ASCII transfer except for the use of the parity bit, the data transfer is very efficient, but not reliable. The parity helps to avoid the inversion of a bit within a character. If several bits of a character are inverted, this error can no longer be detected.

5.2.2 Parameterization data

DS Data record for access using CPU, PROFIBUS and PROFINET
 IX Index for access using CANopen
 SX Subindex for access via EtherCAT

Name	Bytes	Function	Default	DS	IX	SX
PII_L	1	Process image length Input data	Values depend on the parent system	0x02	0x3100	0x01
PIQ_L	1	Process image length Output data		0x02	0x3101	0x02
DIAG_EN	1	Diagnostic interrupt	0x00	0x00	0x3102	0x03
BAUD	1	Baud rate	0x00	0x80	0x3103	0x04
PROTOCOL	1	Protocol	0x01	0x80	0x3104	0x05
OPTION3	1	Character frame	0x13	0x80	0x3105	0x06
OPTION4, 5	2	ZNA 0 ... 65535 (ms)	0	0x80	0x3106 ... 0x3107	0x07 ... 0x08
OPTION6, 7	2	ZVZ 0 ... 65535 (ms)	250	0x80	0x3108 ... 0x3109	0x09 ... 0x0A
OPTION8	1	Qty. Receive buffer	1	0x80	0x310A	0x0B
OPTION9 ... 14	6	reserved	0x00	0x80	0x310B ... 0x3110	0x0C ... 0x11

Tab. 5-1: Parameterization data with ASCII

DIAG_EN Diagnostic interrupt

➔ Enable or disable the diagnostic function here.

Value range 0x00: lock
 0x40: release

Default: 0x00

BAUD transfer rate

➔ Specify the rate of data transmission in bit/s (baud).

The following setting ranges are available; other values are not permitted:

Default: 0x00 (9600 baud)

Value range:

Hex	Baud	Hex	Baud	Hex	Baud
0x00	9600	0x06	2400	0x0C	38400
0x01	150	0x07	4800	0x0D	57600
0x02	300	0x08	7200	0x0E	76800
0x03	600	0x09	9600	0x0F	115200
0x04	1200	0x0A	14400	0x10	109700
0x05	1800	0x0B	19200		

Tab. 5-2: Transfer rate

PROTOCOL

Contains the selected protocol. This setting affects the further structure.

➔ Specify the value 0x01 for the ASCII protocol.

OPTION3**Character frame**

Byte	Bit 7 ... 0	Description	
0	1, 0	binary	Data bits
		00	5 data bits
		01	6 data bits
		10	7 data bits
		11	8 data bits
	3, 2	binary	Parity
		00	none
		01	odd
		10	even
		11	even
	5, 4	binary	Stop bits
		01	1
		10	1.5
		11	2
	7, 6	binary	Flow control
		00	none
		10	Hardware
		11	XON/XOFF

Tab. 5-3: Character frame

Default: 0x13 (data bits: 8, parity: none, stop bit: 1, flow control: none)

Data bits

Number of data bits used to represent a character.

Parity

For the parity check, the parity bit is added to the information bits. Its value (**0** or **1**) completes the value of all bits to obtain a specified state.

If no parity has been specified, the parity bit is set to **1** but not evaluated.

Stop bits

The stop bits are added after each character to be transmitted, they indicate the end of the character.

Flow control

The mechanism which synchronizes the data transfer if the transmitter sends the data faster than the receiver can process them. The flow control can be performed using hardware or software (XON/XOFF).

Hardware flow control

The RTS and CTS lines are used for the hardware flow control.

➔ Wire RTS and CTS correspondingly.

Software flow control

The software flow control uses the control characters XON=0x11 and XOFF=0x13 for control.



When using the software flow control, the data must not contain these two control characters.

**OPTION4, 5
ZNA****Entering waiting time (ZNA)**

➔ Enter ZNA in ms.

The next send job starts only after this waiting time.

Option4 ZNA (High byte)

Option5 ZNA (Low byte)

Value range 0 ... 65535 (ms)

Default: 0

**OPTION6, 7
ZVZ**

The character delay time (ZVZ) defines the maximum permitted time interval between two received characters within a telegram.

Defining ZVZ in ms

➔ Enter a ZVZ between 1 ... 65535.

Communication processor calculates ZVZ

➔ Enter 0 for ZVZ.

The communication processor calculates the ZVZ on the basis of the baud rate (approx. double character time).

Option6 ZVZ (High byte)

Option7 ZVZ (Low byte)

Value range 0 ... 65535 (ms)

Default: 250

**OPTION8
Number Receive
buffers**

Defines the number of receive buffers.

Using 1 receive buffer

➔ Enter the value 1.

If the input buffer is full, no further data can be received.

Using 2 ... 250 receive buffers

➔ Enter a value between 2 ... 250.

The received data are transferred into still free receive buffer.

Value range 0 ... 250

Default: 1

5.3 STX/ETX

5.3.1 Function

Mode of operation

STX/ETX is a simple protocol with header and trailer. STX/ETX is used for transmission of ASCII characters (0x20 ... 0x7F). It is performed without block check character (BCC). Should data from the peripheral devices be read in, STX (start of text) must be available as a start character. The characters to be transmitted follow after that. ETX (end of text) must be available as the end character.

The payload, i.e. all characters between STX and ETX, is transferred to the parent system once the end character ETX has been received. During data transmission, the payload is transferred to the communication processor and from there transmitted to the communication partner with STX as start character and ETX as end character.

Telegram structure




Fig. 5-1: Telegram structure



You can arbitrarily define up to 2 start and end characters and a waiting time (ZNA) for the transmitter.

5.3.2 Parameterization data

DS Data record for access using CPU, PROFIBUS and PROFINET
 IX Index for access using CANopen
 SX Subindex for access via EtherCAT

Name	Bytes	Function	Default	DS	IX	SX
PII_L	1	Process image length Input data	Values depend on the parent system.	0x02	0x3100	0x01
PIQ_L	1	Process image length Output data		0x02	0x3101	0x02
DIAG_EN	1	Diagnostic interrupt	0x00	0x00	0x3102	0x03
BAUD	1	Baud rate	0x00	0x80	0x3103	0x04
PROTOCOL	1	Protocol	0x02	0x80	0x3104	0x05
OPTION3	1	Character frame	0x13	0x80	0x3105	0x06
OPTION4, 5	2	ZNA 0 ... 65535 (ms)	0	0x80	0x3106 ... 0x3107	0x07 ... 0x08
OPTION6, 7	2	TMO 0 ... 65535 (ms)	250	0x80	0x3108 ... 0x3109	0x09 ... 0x0A
OPTION8	1	Number Start flags	1	0x80	0x310A	0x0B
OPTION9	1	Start flag 1	3	0x80	0x310B	0x0C
OPTION10	1	Start flag 2	0	0x80	0x310C	0x0D
OPTION11	1	Number of end flags	1	0x80	0x310D	0x0E
OPTION12	1	End flag 1	3	0x80	0x310E	0x0F
OPTION13	1	End flag 2	0	0x80	0x310F	0x10
OPTION14	1	reserved	0x00	0x80	0x3110	0x11

Tab. 5-4: Parameterization data with STX/ETX

DIAG_EN
Diagnostic interrupt

➔ Enable or disable the diagnostic function here.

Value range 0x00: lock
 0x40: release

Default: 0x00

BAUD
transfer rate

➔ Specify the rate of data transmission in bit/s (baud).

The following setting ranges are available; other values are not permitted:

Default: 0x00 (9600 baud)

Value range:

Hex	Baud	Hex	Baud	Hex	Baud
0x00	9600	0x06	2400	0x0C	38400
0x01	150	0x07	4800	0x0D	57600
0x02	300	0x08	7200	0x0E	76800
0x03	600	0x09	9600	0x0F	115200
0x04	1200	0x0A	14400	0x10	109700
0x05	1800	0x0B	19200		

Tab. 5-5: Transfer rate

PROTOCOL

Contains the selected protocol. This setting affects the further structure.

➔ Specify the value 0x02 for the STX/ETX protocol.

OPTION3
Character frame

Byte	Bit 7 ... 0	Description
0	1, 0	binary Data bits
		00 5 data bits
		01 6 data bits
		10 7 data bits
		11 8 data bits
	3, 2	binary Parity
		00 none
		01 odd
		10 even
		11 even
	5, 4	binary Stop bits
		01 1
		10 1.5
		11 2
	7, 6	binary Flow control
		00 none
		10 Hardware
		11 XON/XOFF

Tab. 5-6: Character frame

Default: 0x13 (data bits: 8, parity: none, stop bit: 1, flow control: none)

Data bits

Number of data bits used to represent a character.

Parity

For the parity check, the parity bit is added to the information bits. Its value (**0** or **1**) completes the value of all bits to obtain a specified state.

If no parity has been specified, the parity bit is set to **1** but not evaluated.

Stop bits

The stop bits are added after each character to be transmitted, they indicate the end of the character.

Flow control

The mechanism which synchronizes the data transfer if the transmitter sends the data faster than the receiver can process them. The flow control can be performed using hardware or software (XON/XOFF).

Hardware flow control

The RTS and CTS lines are used for the hardware flow control.

➔ Wire RTS and CTS correspondingly.

Software flow control

The software flow control uses the control characters XON=0x11 and XOFF=0x13 for control.



When using the software flow control, the data must not contain these two control characters.

**OPTION4, 5
ZNA****Entering waiting time (ZNA)**

➔ Enter ZNA in ms.

The next send job starts only after this waiting time.

Option4 ZNA (High byte)

Option5 ZNA (Low byte)

Value range 0 ... 65535 (ms)

Default: 0

**OPTION6, 7
TMO****Maximum permitted time interval between two telegrams (TMO)**

➔ Enter TMO in ms.

The next telegram must start within the entered time.

Option6 TMO (High byte)

Option7 TMO (Low byte)

Value range 0 ... 65535 (ms)

Default: 250

OPTION8
Number Start flags
Set the number of start flags

➔ Set 1 or 2 start flags.

If 1 is set as the number of start flags, the contents of the 2nd start flag is ignored.

Range 0 ... 2

Default: 1

OPTION9, 10
Start flag 1
Start flag 2

The start flag is sent before a telegram and indicates the start of transmission.

Start flag 1, 2 Range: 0 ... 255

Default: 3 (start flag 1)
0 (start flag 2)

Entering ASCII value of the start character: 1 start flag

✓ The preset value for start flag 2 is 0.

➔ Enter for **Start flag 1** (option9) a value in the range 0 ... 255.

1 start flag is sent before the telegram.

Entering ASCII value of the start character: 2 start flags

➔ Enter 2 for **Number of start flags** (Option8).

➔ Enter for **Start flag 1** (option9) a value in the range 0 ... 255.

➔ Enter for **Start flag 2** (option10) a value in the range 0 ... 255.

2 start flags are sent before the telegram.

OPTION11
Number of end flags
Set the number of end flags

➔ Set 1 or 2 end flags.

If 1 is set as the number of end flags, the contents of the 2nd end flag is ignored.

Range 0 ... 2

Default: 1

OPTION12, 13
End flag 1
End flag 2

The end flag is sent after a telegram and indicates the end of transmission.

End flag 1, 2 Range: 0 ... 255

Default: 3 (end flag 1)
0 (end flag 2)

Entering the ASCII value of the end character: 1 end flag

✓ The preset value for end flag 2 is 0.

➔ Enter for **End flag 1** (option12) a value in the range 0 ... 255.

1 end flag is sent after the telegram.

Entering ASCII value of the end character: 2 end flags

➔ Enter 2 for **Number of end flags** (Option11).

➔ Enter for **End flag 1** (option12) a value in the range 0 ... 255.

➔ Enter for **End flag 2** (option13) a value in the range 0 ... 255.

2 end flags are sent after the telegram.

5.4 3964(R)

5.4.1 Function

3964(R) controls the data transmission for a point-to-point connection between the communication processor and a communication partner. During data transmission, control characters are added to the payload. The communication partner can use these control characters to check whether the data received are complete and free of errors.

The 3964 protocol differs from the 3964R protocol only in the absence of Cyclic_Redundancy_Check (CRC). CRC allows more reliable transmission.

The following control characters are analyzed:

- STX Start of Text
- DLE Data Link Escape
- ETX End of Text
- BCC Block Check Character (only 3964R, BCC is the checksum of the 3964R protocol)
- NAK Negative Acknowledge



DLE duplication

If a DLE is transmitted as information, then it is sent twice to distinguish between the control character DLE and the data characters when establishing and terminating connection. The receiver restores the original state by removing the DLE duplication.



Priority of the communication partners

With 3964(R) a lower priority must be assigned to one communication partner. If both communication partners issue send jobs simultaneously, the partner with lower priority delays its send job.

Procedure




Fig. 5-2: Procedure



The communication processor transmits max. 250 bytes per telegram.

Time-out periods

Character delay time (ZVZ)

- ZVZ is monitored during the entire telegram receiving procedure.

Acknowledgement delay time (QVZ)

- QVZ is monitored between STX and DLE as well as between BCC and DLE.
- After STX: After the QVZ has elapsed after STX, STX is sent again. After 5 attempts a NAK is sent and the attempt to establish connection is terminated. The same happens if a NAK or any optional character is received after an STX.
- After the telegram: After the QVZ has elapsed after the telegram (after BCC byte) or if a character other than DLE has been received, the connection is established anew and the telegram is sent once again. After 5 attempts a NAK is sent and the attempt to establish connection is terminated.

Passive operation

If the driver waits for the connection to be established and a character other than STX is received, it sends NAK. If a NAK character is received, the driver does not send any response.

If the ZVZ is exceeded when receiving data, a NAK is sent and a new attempt to establish connection is awaited.

If the driver is not ready yet when the STX is received, it sends a NAK.

**3964R:
Block Check Character
(BCC byte)**

With 3964R a **B**lock **C**heck **C**haracter is added at the end of the telegram for further data back-up. The BCC byte is formed using an XOR connection for the data of the entire telegram including DLE/ETX.

When receiving a BCC byte which is different from the one that has been determined, a NAK is sent instead of the DLE.

Initialization conflict

If both communication partners are trying to establish connection within QVZ simultaneously, the partner with the lower priority sends the DLE and switches to receiving.

**Data Link Escape
(DLE character)**

The DLE character in a telegram is duplicated by the driver, i.e. DLE/DLE is sent. During receiving procedure, duplicated DLEs are saved as one DLE in the buffer. In 3964R, the end of the telegram is always the combination DLE/ETX/BCC.

Control codes

Command	Code
STX	0x02
ETX	0x03
DLE	0x10
NAK	0x15

5.4.2 Parameterization data

DS Data record for access using CPU, PROFIBUS and PROFINET
 IX Index for access using CANopen
 SX Subindex for access via EtherCAT

Name	Bytes	Function	Default	DS	IX	SX
PII_L	1	Process image length Input data	Values depend on the parent system	0x02	0x3100	0x01
PIQ_L	1	Process image length Output data		0x02	0x3101	0x02
DIAG_EN	1	Diagnostic interrupt	0x00	0x00	0x3102	0x03
BAUD	1	Baud rate	0x00	0x80	0x3103	0x04
PROTOCOL	1	Protocol	0x01	0x80	0x3104	0x05
OPTION3	1	Character frame	0x13	0x80	0x3105	0x06
OPTION4	2	ZNA (x 20 ms)	0	0x80	0x3106	0x07
OPTION5	2	ZVZ (x 20 ms)	10	0x80	0x3107	0x08
OPTION6	2	QVZ (x 20 ms)	10	0x80	0x3108	0x09
OPTION7	2	BWZ (x 20 ms)	10	0x80	0x3109	0x0A
OPTION8	1	STX repetitions	5	0x80	0x310A	0x0B
OPTION9	1	DBL	6	0x80	0x310B	0x0C
OPTION10	1	Priority	0	0x80	0x310C	0x0D
OPTION11 ... 14	4	reserved	0x00	0x80	0x310D ... 0x3110	0x0E ... 0x11

Tab. 5-7: Parameterization data with 3964(R)

DIAG_EN Diagnostic interrupt

➔ Enable or disable the diagnostic function here.

Value range 0x00: lock
 0x40: release

Default: 0x00

BAUD transfer rate

➔ Specify the rate of data transmission in bit/s (baud).

The following setting ranges are available; other values are not permitted:

Default: 0x00 (9600 baud)

Value range:

Hex	Baud	Hex	Baud	Hex	Baud
0x00	9600	0x06	2400	0x0C	38400
0x01	150	0x07	4800	0x0D	57600
0x02	300	0x08	7200	0x0E	76800
0x03	600	0x09	9600	0x0F	115200
0x04	1200	0x0A	14400	0x10	109700
0x05	1800	0x0B	19200		

Tab. 5-8: Transfer rate

PROTOCOL

Contains the selected protocol. This setting affects the further structure.

- ➔ Specify the value 0x03 for the 3964 protocol.
- ➔ Specify the value 0x04 for the 3964R protocol.

Value range 0x03: 3964 Default: 0x03
 0x04: 3964R

OPTION3**Character frame**

Byte	Bit 7 ... 0	Description
0	1, 0	binary Data bits
		00 5 data bits
		01 6 data bits
		10 7 data bits
		11 8 data bits
	3, 2	binary Parity
		00 none
		01 odd
		10 even
		11 even
	5, 4	binary Stop bits
		01 1
		10 1.5
		11 2
	7, 6	reserved

Tab. 5-9: Character frame

Default: 0x13 (data bits: 8, parity: none, stop bit: 1)

Data bits

Number of data bits used to represent a character.

Parity

For the parity check, the parity bit is added to the information bits. Its value (**0** or **1**) completes the value of all bits to obtain a specified state.

If no parity has been specified, the parity bit is set to **1** but not evaluated.

Stop bits

The stop bits are added after each character to be transmitted, they indicate the end of the character.

OPTION4**ZNA****Entering waiting time (ZNA)**

- ➔ Enter ZNA as a factor of 20-ms steps.

The next send job starts only after this waiting time.

Value range 0 ... 255 Default: 0

OPTION5**ZVZ**

The character delay time (ZVZ) defines the maximum permitted time interval between two received characters within a telegram.

Defining ZVZ

- ➔ Enter a ZVZ between 1 ... 255 as a factor of 20-ms steps.

Communication processor calculates ZVZ

- ➔ Enter 0 for ZVZ.

The communication processor calculates the ZVZ on the basis of the baud rate (approx. double character time).

Value range 0 ... 255 Default: 10

OPTION6**QVZ**

The acknowledgment delay time (QVZ) defines the maximum permitted time interval up to the acknowledgment by the partner when establishing or terminating connection.

Entering acknowledgement delay time (QVZ)

➔ Enter QVZ as a factor of 20-ms steps.

Value range 0 ... 255

Default: 10

**OPTION7
BWZ**

The block waiting time (BWZ) is the maximum time between the acknowledgment of a request telegram (DLE) and STX of the reaction telegram.

Entering block waiting time (BWZ)

➔ Enter BWZ as a factor of 20-ms steps.

Value range 0 ... 255

Default: 10

**OPTION8
STX repetitions**

Maximum number of attempts performed by the communication processor when trying to establish connection.

STX repetitions

➔ Enter the max. number of STX repetitions.

Value range 0 ... 255

Default: 5

**OPTION9
DBL**

When the block waiting time (BWZ) is exceeded, you can define the maximum number of repetitions for the request telegram using the DBL parameter.

Entering repetitions for the request telegram (DBL)

➔ Enter for DBL a value between 0 ... 255.

If the attempts are not successful, the transmission is aborted.

Value range 0 ... 255

Default: 6

**OPTION10
Priority**

In 3964(R) the priorities of the communication partners must be different.

Setting priority

➔ Enter 0x00 for the low priority (low).

➔ Enter 0x01 for the high priority (high).

Value range 0x00: low
0x01: high

Default: 0

5.5 Modbus

5.5.1 Overview

	<p>Modbus protocol is a communication protocol with hierarchical structure that specifies one master and several slaves.</p> <p>Modbus functions physically over a serial half-duplex connection as a point-to-point connection with RS232 or as a multipoint connection with RS485.</p>						
Master - Slave communication	<p>Bus conflicts do not occur since the master can always communicate with only one slave. After a request from the master, it waits for the slave response until a configurable waiting time has elapsed. During waiting, communication with another slave is not possible.</p>						
Telegram structure	<p>The request telegrams sent by the master and the response telegrams of a slave have the same structure:</p> <table> <tr> <td>Start character</td><td>Slave Address</td><td>Function Code</td><td>Data</td><td>flow control</td><td>End character</td></tr> </table>	Start character	Slave Address	Function Code	Data	flow control	End character
Start character	Slave Address	Function Code	Data	flow control	End character		
Broadcast with Slave address = 0	<p>A request can be addressed to a certain slave or sent to all slaves as a broadcast message. The slave address 0 is entered to identify a broadcast message.</p> <p>Only writing jobs may be sent as broadcast.</p>						
ASCII- RTU Mode	<p>There are two different transmission modes:</p> <ul style="list-style-type: none"> ■ ASCII mode: Each byte is transmitted in 2-sign ASCII code. The data are marked by the start sign and end sign. This makes the transmission transparent but slow. ■ RTU mode: Each byte is transferred as one character. This leads to higher data throughput than in the ASCII mode. Time monitoring is used instead of start sign and end sign. <p>You can select the mode during parameterization.</p>						

5.5.2 Modbus on the communication processor

Modbus operating modes	<p>The communication processor supports the following Modbus operating modes:</p> <ul style="list-style-type: none"> ■ Modbus Master ■ Modbus Slave short ■ Modbus Slave long
Modbus Master	<p>In the Modbus Master mode, the Modbus communication is controlled by the PLC user program in your parent system.</p> <p>Use the Modbus function code to obtain reading or writing access to your Modbus slaves by means of the Modbus master.</p> <p>In the Modbus Master mode Modbus transmits up to 250 bytes of payload per telegram.</p>
Modbus Slave short	<p>In the Modbus Slave short mode the communication processor communicates with a Modbus master. Depending on the function code, the communication processor receives data from Modbus master or provides data. The data handling on the slave side is performed automatically.</p> <p>In the Modbus Slave short mode Modbus transmits up to 250 bytes of payload per telegram.</p>

Modbus Slave long

In the **Modbus Slave long** mode the communication processor transfers to the parent system only the changed data range starting with 0.

If the Modbus master requests data, a user program must be used to ensure that the relevant data are in the communication processor.

Writing master accesses may not be outside the receiving range.

**NOTE**

Only after all data are available in the communication processor, it sends a response telegram to the master!

5.5.3 Parameterization data

DS Data record for access using CPU, PROFIBUS and PROFINET

IX Index for access using CANopen

SX Subindex for access via EtherCAT

Name	Bytes	Function	Default	DS	IX	SX
PII_L	1	Process image length Input data	Values depend on the parent system	0x02	0x3100	0x01
PIQ_L	1	Process image length Output data		0x02	0x3101	0x02
DIAG_EN	1	Diagnostic interrupt	0x00	0x00	0x3102	0x03
BAUD	1	Baud rate	0x00	0x80	0x3103	0x04
PROTOCOL	1	Protocol	0x0B	0x80	0x3104	0x05
OPTION3	1	Character frame	0x13	0x80	0x3105	0x06
OPTION4	1	Slave address	1	0x80	0x3106	0x07
OPTION5, 6	2	Waiting time	0	0x80	0x3107 ... 0x3108	0x08 ... 0x09
OPTION7 ... 14	8	reserved	0x00	0x80	0x3107 ... 0x3110	0x0A ... 0x11

Tab. 5-10: Parameterization data

DIAG_EN Diagnostic interrupt

➔ Enable or disable the diagnostic function here.

Value range 0x00: lock
 0x40: release

Default: 0x00

BAUD transfer rate

➔ Specify the rate of data transmission in bit/s (baud).

The following setting ranges are available; other values are not permitted:

Default: 0x00 (9600 baud)

Value range:

Hex	Baud	Hex	Baud	Hex	Baud
0x00	9600	0x06	2400	0x0C	38400
0x01	150	0x07	4800	0x0D	57600
0x02	300	0x08	7200	0x0E	76800
0x03	600	0x09	9600	0x0F	115200
0x04	1200	0x0A	14400	0x10	109700
0x05	1800	0x0B	19200		

Tab. 5-11: Transfer rate

PROTOCOL

Contains the selected protocol. This setting affects the further structure. Default value: 0x0B (Modbus Master).

➔ Enter the value from the table for the required Modbus protocol.

ASCII mode	Value	RTU mode	Value
Modbus Master	0x0A	Modbus Master	0x0B
Modbus Slave short	0x0C	Modbus Slave short	0x0D
Modbus Slave long	0x1C	Modbus Slave long	0x1D

Tab. 5-12: PROTOCOL

OPTION3
Character frame

Byte	Bit 7 ... 0	Description
0	1, 0	binary Data bits
		00 5 data bits
		01 6 data bits
		10 7 data bits
		11 8 data bits
	3, 2	binary Parity
		00 none
		01 odd
		10 even
		11 even
	5, 4	binary Stop bits
		01 1
		10 1.5
		11 2
	7, 6	reserved

Tab. 5-13: Character frame

Default: 0x13 (data bits: 8, parity: none, stop bit: 1)

Data bits

Number of data bits used to represent a character.

Parity

For the parity check, the parity bit is added to the information bits. Its value (**0** or **1**) completes the value of all bits to obtain a specified state.

If no parity has been specified, the parity bit is set to **1** but not evaluated.

Stop bits

The stop bits are added after each character to be transmitted, they indicate the end of the character.

OPTION4
Slave address

In Modbus Master the parameter is ignored.

Entering the address for the Modbus slave

➔ Specify an address for the Modbus slave in the Slave protocol.

With this address Modbus accesses the function code.

Value range 0 ... 255

Default: 1

OPTION5, 6 Waiting time

In Modbus slave the parameter is ignored.

Specifying waiting time for the Modbus master

→ Specify a waiting time in ms for the Modbus master. With 0 the waiting time is determined automatically depending on the protocol according to the following formula:

Modbus ASCII	$50 \text{ ms} + (2926000 \text{ ms} / \text{baud rate}) \times \text{bit/s}$	with baud rate in bit/s
Modbus RTU	$50 \text{ ms} + (5190000 \text{ ms} / \text{baud rate}) \times \text{bit/s}$	with baud rate in bit/s

Option5: waiting time (High byte)

Option6: waiting time (Low byte)

Value range: 0...60000 (ms)

Default: 0

5.6 Modbus use

5.6.1 Overview

IO size

The number of input and output data depends on the IO size. For the communication processor it can be parameterized using GSD.

Prerequisite for the operation

The following components are required for the use of Modbus modules:

- Master system consisting of the Cube20S system with communication processor
- Slave system consisting of the Cube20S system with communication processor
- Siemens SIMATIC manager or WinPLC7 by Murrelektronik
- GSD file
- Murrelektronik blocks Fx000011_Vxxx.zip
- Serial connection between both communication processors

Parameterization

Always perform a hardware configuration for the Modbus communication processor. For this purpose, the GSD file by Murrelektronik must be integrated in the hardware catalog.

Procedure for parameterization

- 1 | Plan a Cube20S system.
- 2 | Install the selected GSD file in the hardware catalog.
- 3 | Start the Siemens SIMATIC manager or WinPLC7 by Murrelektronik.
- 4 | Embed a communication processor marked with **Modbus**.
- 5 | Configure the communication processor according to your specifications.
- 6 | Transfer your project to the PLC.

PLC program

Beside **Modbus Slave short**, a PLC program is necessary for the communication. The communication is performed by means of blocks which are embedded in form of Murrelektronik library Fx000011-Vxxx.zip in the configuration tool.

You can find them on our homepage under www.murrelektronik in the Service area.

5.6.2 Communication

Communication options

Below you will find the communication options between Modbus master and Modbus slave.

Combinations:

- Modbus Master ↔ Modbus Slave short
- Modbus Master ↔ Modbus long

Modbus Master ↔ Modbus Slave short

Modbus Master

In the Master mode the communication processor communicates using the blocks FB 60 - SEND and FB 61 - RECEIVE. It transmits up to 250 bytes of payload per telegram.

Modbus Slave short

In the Modbus Slave short mode the amount of payload for input and output is limited by the IO size. Only hardware configuration is required on the slave side for deployment.

Procedure

System structure

- ➔ Install one Cube20S system for master and slave side respectively, it should have a communication processor on each side.
- ➔ Connect both systems using the serial interface.

Planning Modbus Master

- ➔ Plan the master side.
- ➔ Parameterize the communication processor in the hardware configuration.

A PLC user program is required for the communication, the structure of the program should be planned according to the structure in the table (Tab. 5-14:).

OB 100	Single call of the blocks FB 60 - SEND and FB 61 - RECEIVE with all parameters and set R for initialization.
OB 1	Call of FB 60 - SEND with error evaluation. The PLC user program creates the telegram according to the Modbus specifications in the send block.
	Call of FB 61 - RECEIVE with error evaluation. The PLC user program saves the data according to the Modbus specifications in the receive block.

Tab. 5-14: Structure of the PLC user program

Planning Modbus Slave short

- ➔ Plan the slave side.
- ➔ Configure the communication processor in the hardware configuration.
- ➔ Define for the input and output range the start address starting from which the data are saved (depending on the IO size).




Fig. 5-3: System Cube20S Master <-> Slave short

Master ↔ Slave long**Modbus Master**

In the Master mode the communication processor communicates using the blocks FB 60 - SEND and FB 61 - RECEIVE. It transmits up to 250 bytes of payload per telegram.

Modbus Slave long

In the Modbus Slave long mode the communication processor transmits with FB 61 - RECEIVE only the changed data range starting with 0 to the CPU. If the master requests data, the relevant data must be available in the communication processor. With FB 60 - SEND, the CPU transmits the required data range starting with 0 to the communication processor.

Procedure

System structure

- ➔ Install one Cube20S system for master and slave side respectively, it should have a communication processor on each side.
- ➔ Connect both systems using the serial interface.

Planning Modbus Master

- ➔ Plan the master side.
- ➔ Configure the communication processor in the hardware configuration.

A PLC user program is required for the communication, the structure of the program should be planned according to the structure in the table (Tab. 5-15:).

OB 100	Single call of the blocks FB 60 - SEND and FB 61 - RECEIVE with all parameters and set R for initialization.
OB 1	Call of FB 60 - SEND with error evaluation. The PLC user program creates the telegram according to the Modbus specifications in the send block.
	Call of FB 61 - RECEIVE with error evaluation. The PLC user program saves the data according to the Modbus specifications in the receive block.

Tab. 5-15: Structure of the PLC user program

Planning Modbus Slave long

- ➔ Plan the slave side.
- ➔ Configure the communication processor in the hardware configuration.

A PLC user program is required for the communication, the structure of the program should be planned according to the structure in the table (Tab. 5-16:).

OB 100	Single call of the blocks FB 60 - SEND and FB 61 - RECEIVE with all parameters and set R for initialization.
OB 1	Call of FB 60 - SEND with error evaluation. The PLC user program saves a range starting with 0 in the communication processor which can be accessed by the master via Modbus.
	Call of FB 61 - RECEIVE with error evaluation. The communication processor transfers a data range into the CPU.
	If the data are changed by the master, the CPU receives only the data which have been changed.

Tab. 5-16: Structure of the PLC user program




Fig. 5-4: System Cube20S Master ↔ Slave long

5.7 Modbus function codes

5.7.1 Definitions

Naming conventions for Modbus

Modbus distinguishes between bit and word access

- Bit = **Coil**
- Word = **Register**
- Bit input = **Input status**
- Bit output = **Coil status**
- Word input = **Input register**
- Word output = **Holding register**




Fig. 5-5: Naming conventions

Range definitions

Usually Modbus accesses using the ranges 0x, 1x, 3x and 4x.

- 0x and 1x: Access to digital bit ranges
- 3x and 4x: Access to analog word ranges



NOTE

The communication processor does not distinguish between digital and analog data, therefore, the assignment in the table (Tab. 5-17:) applies.

Range		Access using function code
0x	Bit range for the output data of the master	0x01, 0x05, 0x0F
1x	Bit range for the input data of the master	0x02
3x	Word range for the input data of the master	0x04
4x	Word range for the output data of the master	0x03, 0x06, 0x10

Tab. 5-17: Assignment of the bit and word ranges




Fig. 5-6: Range definitions

5.7.2 Overview

Access

Using the following function codes you can access a slave from a Modbus master. The function codes are described from the point of view of the master.

Code	Command	Description
0x01	Read n bits	Read n bits of master output range 0x
0x02	Read n bits	Read n bits of master input range 1x
0x03	Read n words	Read n words of master output range 4x
0x04	Read n words	Read n words of master input range 3x
0x05	Write 1 bit	Write 1 bit in master output range 0x
0x06	Write 1 word	Write 1 word in master output range 4x
0x0F	Write n bits	Write n bits in master output range 0x
0x10	Write n words	Write n words in master output range 4x

Tab. 5-18: Access

View for **input** and **output** data

The function codes are described from the point of view of the master.

Data sent by the master to the slave are referred to as **output** data (OUT) up to the target.

Data received by the master from the slave, are referred to as **input** data (IN).




Fig. 5-7: View for input and output data

Response of the slave

If the slave responds with an error, the function code is returned with **OR 0x80**.

If there is no error, the function code is returned.

Slave response: Function code OR 0x80 → Error
 Function code → OK



NOTE

The following applies to the order of bytes in a word:

1 word	
High byte	Low byte

**Checksum
CRC or LRC**
CRC in the RTU mode, LRC in the ASCII mode

The checksums are automatically attached to each telegram. They are not displayed in the data block.

Slave address

The slave address must be identical with the parameterized **slave address** (OPTION4).

5.7.3 Function codes

Read n bits 0x01, 0x02

Code 0x01: Read n bits of master output range 0x

Code 0x02: Read n bits of master input range 1x

Slave Address	Function code	Address 1st bit	No. of bits	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 word

Tab. 5-19: Command telegram

Slave address	Function code	Number of the read bytes	Data 1st byte	Data 2nd byte	...	Checksum CRC/LRC
1 byte	1 byte	1 byte	1 byte	1 byte		1 word
				max. 250 bytes		

Tab. 5-20: Response telegram

**Read n words
0x03, 0x04**

0x03: Read n words of master output range 4x

0x04: Read n words of master input range 3x

Slave address	Function code	Address 1st bit	No. of words	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 word

Tab. 5-21: Command telegram

Slave address	Function code	Number of the read bytes	Data 1st word	Data 2nd word	...	Checksum CRC/LRC
1 byte	1 byte	1 byte	1 word	1 word		1 word
				max. 125 words		

Tab. 5-22: Response telegram

Write 1 bit 0x05

Code 0x05: Write 1 bit in master output range 0x

The status is changed in **Statusbit** with the following values:

Status bit = 0x0000 → bit = 0

Status bit = 0xFF00 → bit = 1

Slave address	Function code	Address Bit	Bit status	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 word

Tab. 5-23: Command telegram

Slave address	Function code	Address Bit	Bit status	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 word

Tab. 5-24: Response telegram

Write 1 word 0x06

Code 0x06: Write 1 word in master output range 4x

Slave address	Function code	Address Word	Value Word	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 word

Tab. 5-25: Command telegram

Slave address	Function code	Address Word	Value Word	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 word

Tab. 5-26: Response telegram

Write n bits 0x0F

Code 0x0F: Write n bits in master output range 0x

The number of bits has also to be specified in bytes.



Slave address	Function code	Address 1st bit	No. of bits	No. of bytes	Data 1st byte	Data 2nd byte	...	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 byte	1 byte	1 byte	1 byte	1 word
					max. 250 bytes			

Tab. 5-27: Command telegram

Slave address	Function code	Address 1st bit	No. of bits	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 word

Tab. 5-28: Response telegram

Write n words 0x10

Code 0x10: Write n words in master output range

Slave address	Function code	Address 1st word	No. of words	No. of bytes	Data 1st word	Data 2nd word	...	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 byte	1 word	1 word	1 word	1 word
					max. 125 words			

Tab. 5-29: Command telegram

Slave address	Function code	Address 1st word	No. of words	Checksum CRC/LRC
1 byte	1 byte	1 word	1 word	1 word

Tab. 5-30: Response telegram

5.8 Modbus - Error messages

Overview

For the communication in Modbus, there are 2 error types:

- Master does not receive any valid data
- Slave responds with an error message

Master does not receive any valid data

If the slave does not respond within the predefined waiting time or if a telegram is faulty, the master enters an error message in plain text in the receiving block.

Error messages

ERROR01 NO DATA	Error no data The master has not received any telegram within the waiting time.
ERROR02 D LOST	Error data lost No data are available. The receive buffer is either full or an error occurred in the reception buffer.
ERROR03 F OVERF	Error frame overflow Master has not recognized the telegram end and the maximum telegram length has been exceeded.
ERROR04 F INCOM	Error frame incomplete Master has only received a partial telegram.
ERROR05 F FAULT	Error frame fault The checksum within a telegram is not correct.
ERROR06 F START	Error frame start The start character is incorrect.

NOTE: The error can only occur with Modbus-ASCII.

Slave responds with an error message

If the slave responds with an error, the function code is returned with 0x80 **logical OR connection**.

Example:

DB11.DBD 0	DW#16#05900000	Response telegram
	with 05 →	Slave address 0x05
	90 →	Function code 0x90 (error message, because 0x10 OR 0x80 = 0x90)
	0000 →	The residual data are irrelevant because an error has been reported back

6 General data

Conformity			
	CE	2004/108/EC	EMC Directive
		2011/65/EU	RoHS
Personal and device protection			
	Ingress protection	EN 60529	IP20
	Electric isolation		
	To fieldbus	-	DC-isolated
	To process level	-	DC-isolated
	Dielectric strength	EN 61131-2	-
	Insulation voltage to ground		
	Inputs / outputs	-	50 V AC/DC, with test voltage 500 V AC
	Protective measures	-	against short-circuit
Ambient conditions			
	Climatic		
	Storage / transport	EN 60068-2-14	-25 ... +70 °C
	Operation		
	Horizontal installation	EN 61131-2	0 ... +60 °C
	Vertical installation	EN 61131-2	0 ... +60 °C
	Humidity	EN 60068-2-30	RH1 (without condensation, relative humidity 10 ... 95 %)
	Pollution	EN 61131-2	Pollution degree 2
	Mechanical		
	Vibration	EN 60068-2-6	1 g, 9 Hz ... 150 Hz
Shock	EN 60068-2-27	15 g, 11 ms	
Installation conditions			
	Place of installation	-	Inside the switch cabinet
	Installation position	-	Horizontal and vertical
	Fastening	-	35 mm DIN rail
Mechanical data		Housing	
	Material	PPE / PPE GF10	
	Dimensions (W x H x D)	12.9 x 109 x 76.5 mm	
	Weight	60 g	
Ambient conditions			
	Operating temperature	0 °C to 60 °C	
	Storage temperature	-25 °C to 70 °C	
Certifications			
	Certification according to UL 508		yes

EMC / Standard			Notes
	Emitted interference	EN 61000-6-4	Class A (industrial environments)
	Immunity Zone B	EN 61000-6-2	Industrial environments
		EN 61000-4-2	ESD 8 kV with air discharge (severity grade 3), 4 kV with contact discharge (severity grade 2)
		EN 61000-4-3	HF irradiation (housing) 80 MHz ... 1000 MHz, 10 V/m, 80 % AM (1 kHz) 1.4 GHz ... 2.0 GHz, 3 V/m, 80 % AM (1 kHz) 2 GHz ... 2.7 GHz, 1 V/m, 80 % AM (1 kHz)
		EN 61000-4-6	conducted 150 kHz ... 80 MHz, 10 V, 80 % AM (1 kHz)
		EN 61000-4-4	Burst, severity grade 3
		EN 61000-4-5	Surge, installation class 3 *)

*) Due to single high-energy impulses, a suitable external wiring with lightning protection elements is required for surge, e.g. lightning arresters and surge arrester.

7 Technical data

Power consumption / power dissipation		
	Power consumption from the backplane bus	100 mA
	Power consumption from load voltage L+ (without load)	10 mA
	Power dissipation	1 W
Status, interrupt, diagnoses		
	Status indication	yes
	Alarms	yes, programmable
	Process interrupt	no
	Diagnostic interrupt	yes, programmable
	Diagnostic function	yes, programmable
	Diagnostic information readable	possible
	Supply voltage indication	Green LED
	Collective error indication	Red LED
	Channel error	Red LED
Point-to-Point communication		
	PtP communication	yes
	Interface, electrically isolated	yes
	RS232 interface	yes
	RS422 interface	-
	RS485 interface	-
	Connection	Terminal module
	Min. transfer rate	150 bit/s
	Max. transfer rate	115.2 kbit/s
	Cable length, max.	15 m
Point-to-Point protocols		
	Protocol ASCII	yes
	Protocol STX/ETX	yes
	Protocol 3964(R)	yes
	Protocol RK512	-
	Protocol USS Master	-
	Protocol Modbus Master	yes
	Protocol Modbus Slave	yes
	Special protocols	-
Data sizes		
	Input bytes	8 / 20 / 60
	Output bytes	8 / 20 / 60
	Parameter bytes	21
	Diagnostic bytes	20

7.1 Protocols

ASCII	
Telegram length	max. 1024 bytes
Baud rate	150, 300, 600, 1 200, 1 800, 2 400, 4 800, 7 200, 9 600, 14 400, 19 200, 38 400, 57 600, 76 800, 109 700, 115 200 baud
Character delay time (ZVZ)	0 ... 65 535 (in ms steps), with ZVZ = 0 the 3-fold character time is used.
Flow control	no hardware, XON/XOFF
Number of telegrams which can be buffered	max. 250
End flag of a telegram	after the character delay time (ZVZ) has elapsed

STX/ETX	
Telegram length	max. 1,024 bytes
Baud rate	150, 300, 600, 1 200, 1 800, 2.400, 4 800, 7 200, 9 600, 14 400, 19 200, 38 400, 57 600, 76 800, 109 700, 115 200 baud
Character delay time (TMO)	0 ... 65 535 (in ms steps), with TMO = 0 the 3-fold character time is used.
Flow control	no hardware, XON/XOFF
Number of telegrams which can be buffered	max. 250
End flag of a telegram	using parameterized end character
Number of start characters	0 ... 2 (characters, programmable)
Number of end characters	0 ... 2 (characters, programmable)
3964, 3964R	
Telegram length	max. 1,024 bytes
Baud rate	150, 300, 600, 1 200, 1 800, 2.400, 4 800, 7 200, 9 600, 14 400, 19 200, 38 400, 57 600, 76 800, 109 700, 115 200 baud
Block check character	only 3964R
Priority	low/high
Character delay time (ZVZ)	0 ... 255 (in 20-ms steps), with ZVZ = 0 the 3-fold character time is used.
Acknowledgement delay time (QVZ)	0 ... 255 (in 20-ms steps), with QVZ = 0 the 3-fold character time is used.
Number of connection attempts	0 ... 255
Number of transfer attempts	1 ... 255
Modbus	
Telegram length	max. 258 bytes
Baud rate	150, 300, 600, 1 200, 1 800, 2.400, 4 800, 7 200, 9 600, 14 400, 19 200, 38 400, 57 600, 76 800, 109 700, 115 200 baud
Mode	Master ASCII, Master RTU, Slave ASCII short, Slave RTU short, Slave ASCII long, Slave, RTU long
Address	1 ... 255
Waiting time	automatic, 1 ... 60,000 ms

8 Annex

8.1 Accessories

Bus cover
Art. no. 57190



Fig. 8-1: Bus cover

Carrier for shield busses



The shield busses (10 mm x 3 mm) to connect cable shields are fastened on the carrier.

NOTE

Carriers for shield busses, shield busses and cable shield fasteners are not included in the delivery.

Installing the carrier

- ✓ Prerequisite: The Cube20S system has been completely mounted.
- ➔ If the DIN rail is flat, break the spacer off the carrier.
- ➔ Plug the carrier in the terminal module below the terminal block until it engages.




Fig. 8-2: Installing the carriers for shield busses

8.2 Glossary

General terms:

Term	Meaning
Intended purpose	Use of a product, process, or feature according to the specifications, instructions, and information supplied by the MANUFACTURER.
Bit	Binary digit
Byte	1 byte corresponds to 8 bit
DI	Digital inputs
DIN	Deutsches Institut für Normung (German Institute for Standardization)
I/O	Input/Output
Directive 2004/108/CE	EMC Directive
EMC	Electromagnetic compatibility
EN	European standard
ESD	Electrostatic discharges
FE	Functional earth
I	Current
IEC	International Electrotechnical Commission, international standardization institute
IN	Input
IP20	Ingress Protection, protection class according to DIN EN 60529 1st code digit = Protection against accidental contact and solid foreign objects 2nd code digit = Protection against ingress of water 2: protected against: solid foreign objects with diameter starting from 12.5 mm and contact with a finger. 0: No protection
IP67	6: Dustproof, protection against contact with a wire 7: Protection against the effects of temporary submersion in water
ISO	International Standard Organization
LED	Light Emitting Diode
n. c.	not connected
OUT	Output
PELV	Protective Extra Low Voltage
SELV	Safety Extra Low Voltage
U	Voltage
U/I	Voltage / current

8.3 Legal information

Exclusion of liability

Murrelektronik GmbH checked the contents of this technical documentation for conformity with the described hardware and software. Changes on an individual case basis cannot be excluded. For this reason, we shall not assume any responsibility for errors or omissions, in particular for a complete conformity. This exclusion of liability shall not apply in case the damage is caused deliberately and/or due to gross negligence as well as for all claims based on the German Product Liability Act. Should a major contractual obligation negligently be violated, the liability of Murrelektronik GmbH shall be limited to damages that typically arise.

Subject to technical modifications or changes with regard to contents. We recommend to regularly check whether this documentation has been updated because corrections that might be required due to technical modifications will be included by Murrelektronik GmbH at regular intervals. We are always grateful for any proposals of improvement.

Copyright

It is prohibited to transfer or photocopy the documentation either in paper or in digital form, reuse or divulge its contents unless otherwise expressly permitted by Murrelektronik GmbH or in conjunction with the production of documentation for third-party products that contain products made by Murrelektronik GmbH. Any violation of this provision will result in liability for damage. All rights reserved, in particular in the event of the award of patents or registration of utility models.

Rights of use

Murrelektronik GmbH grants its customers a non-exclusive right revocable at any time and for an indefinite period of time to use this technical documentation to produce their own technical documentation. For this purpose, the documentation produced by Murrelektronik GmbH may be changed in parts, or amended, or copied, and transferred to the customer's users as part of the customer's own technical documentation on paper or on electronic media. In this case, the customers shall bear sole responsibility for the correctness of the contents of the technical documentation produced by them.

If the technical documentation is integrated in part, or in full in the customer's technical documentation, the customer shall refer to the copyright of Murrelektronik GmbH. Furthermore, special attention shall

be paid to compliance with the safety instructions.

Although the customers are obliged to make reference to the copyright of Murrelektronik GmbH, provided the technical documentation of Murrelektronik GmbH is used, the customers shall market and/or use the technical documentation on their sole responsibility. The reason is that Murrelektronik GmbH has no influence on changes or applications of the technical documentation and even minor changes to the starting product or deviations in the intended applications may render incorrect the specifications contained in the technical documentation. For this reason, the customers are obliged to identify the technical documentation originating from Murrelektronik GmbH if and inasmuch as the documentation is changed by the customers. The customers shall undertake to exempt Murrelektronik from the damage claims of third parties if the latter are attributable to any deficits in the documentation. This shall not apply to damages to the rights of third parties caused deliberately or by gross negligence.

The customers shall be entitled to use the company brands of Murrelektronik GmbH exclusively for their product advertising, but only inasmuch as the products of Murrelektronik GmbH are integrated in the products marketed by the customers. When using Murrelektronik GmbH brands, the customers shall mention this in an adequate manner.

