

- Introduction
- For your own safety
- System description
- Art. no. Counter module 57161 1X32 bits 2 MHz
- General data
- Technical data
- Annex

CUBE20S Expansion manual

Counter module 1x 32 bits, up to 2 MHz

This document is valid for the following products:

| Name | Art. no. |
|---|-----------------|
| CUBE20S system | 57161 |
| Counter module 1x 32 bits, up to 2 MHz | |
| Counter modules incl. base | |

Status

Manual no.: 57161_hdb_en_10

Language: EN

Version: 1.0

Date: 10.7.14

Contact

Murrelektronik GmbH

Falkenstraße 3

D-71570 Oppenweiler

Phone +49 (0) 7191 47-0

Fax +49 (0) 7191 47-491000

info@murrelektronik.de

Table of contents

| | | |
|----------|--|-----------|
| 1 | Introduction | 4 |
| 1.1 | Service and support | 4 |
| 1.2 | Introduction / about this document | 5 |
| 1.3 | Applicable documents | 5 |
| 1.4 | Symbols | 5 |
| 1.5 | Trademarks | 6 |
| 2 | For your own safety | 7 |
| 2.1 | Target group | 7 |
| 2.2 | Intended purpose | 7 |
| 2.3 | General safety instructions | 7 |
| 2.4 | Notes on electrostatically sensitive equipment | 8 |
| 2.5 | EMC installation guidelines | 8 |
| 2.6 | Notes on spare parts and accessories | 9 |
| 2.7 | Environmentally friendly disposal | 9 |
| 2.8 | EC Declaration of Conformity | 9 |
| 2.9 | Warranty and liability | 10 |
| 3 | System description | 11 |
| 3.1 | System | 11 |
| 3.2 | Dimensions | 14 |
| 3.3 | Mounting | 15 |
| 3.4 | Disassembling and replacing modules | 19 |
| 3.5 | Wiring | 25 |
| 3.6 | Troubleshooting - LEDs | 31 |
| 4 | Art. no. Counter module 57161 1X32 bits 2 MHz | 33 |
| 4.1 | Features | 33 |
| 4.2 | Design | 33 |
| 4.3 | Quick start | 36 |
| 4.4 | Input/output range | 39 |
| 4.5 | Parameterization | 41 |
| 4.6 | Counter functions | 43 |
| 4.7 | Additional functions Counter | 52 |
| 4.8 | Diagnosis and interrupt | 57 |
| 5 | General data | 60 |
| 6 | Technical data | 62 |
| 7 | Annex | 64 |
| 7.1 | Accessories | 64 |
| 7.2 | Glossary | 65 |
| 7.3 | Legal information | 66 |

1 Introduction

1.1 Service and support

| | |
|--|---|
| Sales | Our sales staff in the company, field service and technicians will support you at all times. |
| CONNECTIVITY system consultants | <p>Our system consultants are your competent contact persons when you want to develop CONNECTIVITY solutions. Together with you, they find the optimum solutions for your electrical installations.</p> <p>Our CONNECTIVITY consultants find ways that help you to permanently improve the competitiveness of your machines and plants.</p> |
| Customer Service Center (CSC) | <p>Our staff of the Customer Service Center will help you with all questions concerning installation and set-up. They support you, for example, if you have problems when combining hardware and software products of different manufacturers.</p> <p>There are numerous support tools and possibilities for measurements - both for fieldbus systems and electromagnetic interference.</p> <p>Please do not hesitate to call us on +49 (0) 7191 47-2050 or send us an e-mail to: csc@murrelektronik.de.</p> |
| Service addresses | <p>Please see our website for your contact person:</p> <p>www.murrelektronik.com</p> |

1.2 Introduction / about this document

Function of this document

This document describes the use of the module **Counter module 1x 32 bits, up to 2 MHz** from the Cube20S system of Murrelektronik GmbH. It includes a description of the design, engineering and application.

1.3 Applicable documents

Applicable documents

| Document | Location |
|------------------|------------------------------------|
| Operating manual | Online shop of Murrelektronik GmbH |

1.4 Symbols

This document includes information and notes that have to be observed for your own safety and to avoid personal and material damage. They are characterized as follows:



DANGER!

Immediate danger

→ Failure to observe this warning involves an imminent risk of death or serious injuries!



WARNING!

Possible danger

→ Failure to observe this warning may cause death or serious injuries.



CAUTION!

Low-risk danger

→ Failure to observe this warning causes minor to moderate injuries.

NOTICE

Risk of material damage

→ Failure to observe this warning causes material damage.



NOTE

Other technical information and notes of Murrelektronik GmbH.



RECOMMENDATION

Notes with this symbol are recommendations of Murrelektronik GmbH.



Products and Accessories

This symbol refers to accessories or product recommendations.

Instruction for use

- ➔ An arrow marks instructions for use.
- ➔ Read and observe the instructions for use.
- 1 | If they are numbered, it is absolutely necessary to follow them in the correct order.
- 2 | Read and observe the instructions for use.

1.5 Trademarks

The trademarks of the following companies are used in this documentation:

| | |
|---|---|
| Adobe Systems Corp. | Adobe Acrobat Reader |
| Microsoft Corp. | Microsoft Windows 7, Windows Vista, Windows 2000, Windows XE/XP and Microsoft Internet Explorer |
| PROFIBUS International (P.I.) | PROFIBUS, PROFIBUS DP |
| PROFIBUS / PROFINET International (P.I.) | PROFINET, PROFINET IO |
| ODVA Open DeviceNet Vendor Association | EtherNet/IP |
| Beckhoff Automation GmbH | EtherCAT |
| CAN in AUTOMATION - International Users and Manufacturers Group e.V. | CANopen |
| Gould Inc. Corporation | Modbus |
| Siemens AG | S5-200, S5-300, S5-400 S7-200, S7-300, S7-400 |

2 For your own safety

2.1 Target group

| | |
|----------------------|--|
| Users | This manual is intended for users who have knowledge of automation systems. |
| Documentation | Please give this manual to all employees involved in the following tasks: <ul style="list-style-type: none">■ Planning■ Installation■ Set-up■ Operation |

2.2 Intended purpose

| | |
|---------------------------|---|
| Designated use | The Cube20S system has been designed and manufactured for: <ul style="list-style-type: none">■ communication and process control■ general control and automation tasks■ industrial use■ operation under the ambient conditions specified under technical data■ installation in a switch cabinet |
| Foreseeable misuse | The device is not approved for being used: <ul style="list-style-type: none">■ in potentially explosive atmospheres (EX Zone)■ outside of switch cabinets. |

2.3 General safety instructions

Note:

- the relevant safety and accident prevention regulations;
- the EC Directives or other national regulations;
- generally recognized safety rules;
- the section 2.5 "EMC installation guidelines".

NOTICE

Defective device!

Improper use of the hardware and software can cause damage to the device.

- Only qualified personnel of Murrelektronik GmbH may manipulate the device.
- Only use the device to the extent described in the manual.

Avoid accidents caused by electrical voltage!

- Comply with the 5 safety rules of electrical engineering!
- Disconnect the device from the mains.
- Then carry out installation or repair work.

Avoid personal and material damage due to malfunctions!

- Provide external circuit breakers.
- The device may only be operated within the specified tolerances.

Avoid undefined states!

- ➔ Select and install connection lines so that capacitive and inductive interferences do not have adverse effects on the system.
- ➔ Protect the device against improper and unintended use.

2.4 Notes on electrostatically sensitive equipment

NOTICE**Overvoltage due to electrostatic discharge!**

The assemblies might get damaged.

- ➔ Ensure sufficient grounding of persons and working material!

Handling

Murrelektronik assemblies include highly integrated MOS components. These components are extremely sensitive to over-voltages occurring, for example, due to electrostatic discharge. Assemblies at risk are marked by the adjacent symbol.

The symbol is fixed to assemblies, sub-racks or packaging and indicates electrostatically sensitive equipment. These assemblies may become irreparably damaged by voltage and energy levels which are far below the perception levels of human beings.

If a person who is not electrostatically discharged handles electrostatically sensitive equipment, voltages may be produced. They may damage components, impair the functioning of the assemblies or render the assembly inoperative. Frequently, assemblies damaged like this cannot directly be recognized as faulty. The fault may show only after longer operation.

Components damaged by electrostatic discharge may produce temporary faults in case of temperature changes, vibrations or load changes.

Only with a consistent use of protective devices and a responsible compliance of the instructions for use can you avoid malfunctions or failures of the electrostatically sensitive equipment.

Shipping

- ➔ For shipping electrostatically sensitive equipment, use **always** the original packaging.

Measurements

Observe the following notes for measurements on electrostatically sensitive equipment:

- ➔ Discharge potential-free measuring instrument briefly.
- ➔ Ground the measuring instruments used.

Modifications

Observe the following in case of modifications on electrostatically sensitive equipment:

- ➔ Use a grounded soldering iron.

2.5 EMC installation guidelines

Industrial use

The CUBE20S system is an electronic device manufactured according to the current state-of-the-art standards. Both the robust mechanical construction and the design of the electronic components make it ideal for industrial use.

To guarantee a trouble-free operation, observe the following rules when installing the device in systems. Otherwise, the high interference immunity and resistance to damage of the device may become partially ineffective.

The interference immunity of the entire system considerably depends on the correct installation, location and wiring.

- 1 | For safe operation, check the installation regulations stipulated by the manufacturer of the controller.
- 2 | Bring them in line with the recommendations for an EMC-compatible design.
- 3 | Then install CUBE20S system.

2.6 Notes on spare parts and accessories

Spare parts

- Only use the original spare parts or spare parts by other manufacturers expressly authorized by Murrelektronik GmbH.
- Check the function of the device after having replaced a component.

Accessories

- The use of accessories may alter the device function. Use only accessories authorized by Murrelektronik GmbH.
- Observe the enclosed instructions of the accessories when installing them.

2.7 Environmentally friendly disposal



Disposal

Do not throw electrical devices, batteries or accumulators in the domestic waste!

If you want to dispose of the product, it may be returned free of charge to Murrelektronik GmbH. This is also valid for original packaging and batteries or accumulators.

Return

- ➔ Label the product and the packaging with "**For disposal**".
- ➔ Pack the product.
- ➔ Send the package to:
Murrelektronik GmbH
Falkenstraße 3
D-71570 Oppenweiler

We ensure that it is disposed of according to the German legislation. Transport to the place of destination is at the expense of the last owner.

2.8 EC Declaration of Conformity



Murrelektronik GmbH herewith declares that the products and systems comply with the basic requirements and other relevant regulations of the following Directives:

- 2004/108/EC Electromagnetic compatibility
- 2011/65/EU RoHS

2.9 Warranty and liability

Warranty and liability claims

Warranty and liability claims shall be lost if

- the product is not used according to its designated use,
- damage is caused because the manual and the operating instructions have not been observed,
- the staff was/is not qualified.

3 System description

3.1 System

Overview

The Cube20S system is a modular automation system mounted on a 35 mm DIN rail. Using 2, 4 and 8-channel expansion modules, you may adapt this system perfectly to your automation tasks.

You do not need much wiring because the 24 V DC power supply is integrated in the backplane bus. Defective electronic modules can be replaced without having to replace the wiring.

Using power modules with different colors, you may define further voltage ranges for the 24 V DC power supply within the system or add 2 A to the electronic supply.





Fig. 3-1: Cube20S system

Components

The Cube20S system consists of the following components:

- Bus node
- Expansion modules
- Power modules
- Accessories

Bus node



Bus interface and power module of the bus node are incorporated in one housing. The bus interface is used to connect to a parent bus system.


Both bus interface and the electronics of the connected expansion modules are supplied with power over the power module.

There is another connection on the power module for the 24 V DC power supply of the connected expansion modules.

By installing up to 64 expansion modules on the bus node, they will be electrically connected, i.e.

- they are incorporated in the backplane bus,
- the electronic modules are supplied with power,
- each expansion module is connected to the 24 V DC power supply.

Bus cover




Each bus node has a cover to protect the contacts.

- ➔ Remove the cover on the bus node before installing CUBE20S modules.
- ➔ To protect the contacts, mount the bus cover on the outmost module.


Expansion modules

Each expansion module consists of a terminal and an electronic module.



- 1 Terminal module
- 2 Electronic module

Terminal module




The terminal module consists of the following functional elements:

- a sliding mechanism to fasten the electronic module,
- the backplane bus with power supply for the electronics,
- the connection to the 24 V DC power supply,
- the staircase-shaped terminal block for wiring,
- a safe locking system for fastening on a mounting rail.

This locking mechanism allows you to mount your Cube20S system outside the switch cabinet and fix the complete system later in the switch cabinet.


Electronic module



The functionality of an expansion module is defined over the electronic module.

- If the electronic module is defective, it can be replaced while wiring is kept.
- On its front, there are LEDs indicating the status.
- For an easier wiring, there are wiring diagrams on the front and side of each electronic module.

Power modules



Power modules provide the Cube20S system with power. The power modules are either integrated in the bus node or may be plugged between the expansion module.

Depending on the type of power module, groups of potential can be defined for the 24 V DC power supply, or the electronics supply may be extended by 2 A.

For a better recognition, the power modules have a different color than the expansion modules.

3.2 Dimensions

Dimensions of the bus node



Fig. 3-2: Dimensions of the bus node

Dimensions of the expansion module




Fig. 3-3: Dimensions of the expansion module

Dimensions of the electronic module




Fig. 3-4: Dimensions of the electronic module

3.3 Mounting



NOTE

You can mount the modules individually or as a whole block on the DIN rail. For block installation, please observe the following: **All** locking levers must be open.

3.3.1 General notes

The individual modules are mounted directly on a DIN rail. Electronics and power supply are connected over the backplane bus.

Conditions:

- Max. number of plug-in modules: 64
- Max. total current of the electronics supply: 3 A

A **power module sensor/actuator/bus art. no. 57131** extends the current for the electronics supply by 2 A. For details, refer to section 3.5 "Wiring".




Fig. 3-5: Installing the module

3.3.2 Functional principle of the locking

Inserting and locking the module

- ✖ The terminal module has a locking lever at its top.
- 1 | For installation and disassembly, please press this lever upwards until it engages audibly.
- 2 | Plug the module to be mounted in the previously plugged-in module.
- 3 | Slide the module with the help of the guide strips at top and bottom onto the DIN rail.
- 4 | Flap the locking lever downwards.

The module is fastened to the DIN rail.

3.3.3 Replacing an electronic module

Disassembly

- ✓ The electronic module has a locking lever at the bottom.
- 1 | Press the locking lever upwards for disassembly.
- 2 | To remove the electronic module, pull it out towards the front.

The electronic module has been removed.

Installation

- ✓ The electronic module has a locking lever at the bottom.
- ➔ Slide the electronic module with the help of the guide strip into the terminal module.

The electronic module engages audibly at the bottom.




Fig. 3-6: Disassembling and installing the electronic module

3.3.4 Installing the DIN rail

- ➔ Install the DIN rail with the necessary distances (see Fig. 3-7: "Installation distances").




Fig. 3-7: Installation distances

3.3.5 Installing the bus node

- ✓ To mount the system, start on the left with the bus node.
- 1 | Flap the two locking levers of the bus node upwards.
- 2 | Plug the bus node in the DIN rail.
- 3 | Flap the two locking levers of the bus node downwards.
- 4 | To remove the right bus cover, pull it out towards the front.
- 5 | Store the bus cover to use it as termination of the system.




Fig. 3-8: Installing the bus node

3.3.6 Installing the expansion modules

- 1 | Flap the locking lever of the expansion module upwards.
- 2 | Plug the expansion module in the DIN rail.
- 3 | Push the expansion module towards the bus node or the last expansion module.
- 4 | Flap the locking lever of the expansion module downwards.
- 5 | Mount all expansion modules as described.




Fig. 3-9: Installing the expansion module

3.3.7 Installing the bus cover

- ✓ Prerequisite: The system has been completely mounted.
- ➔ Plug the bus cover in the outmost module as a protection of the bus contacts.




Fig. 3-10: Installing the bus cover

3.4 Disassembling and replacing modules

3.4.1 Procedure

During disassembly or when replacing a module or module group, please observe the following:

- 1 | Remove the electronic module to the right of the module or module group.
- 2 | Dismount/replace the module or module group.
- 3 | Plug in the electronic module.

3.4.2 Replacing an electronic module

Disassembly

- ✓ The electronic module has a locking lever at the bottom.
- 1 | Press the locking lever upwards for disassembly.
- 2 | To remove the electronic module, pull it out towards the front.

The electronic module has been removed.

Installation

- ✓ The electronic module has a locking lever at the bottom.
- ➔ Slide the electronic module with the help of the guide strip into the terminal module.

The electronic module engages audibly at the bottom.




Fig. 3-11: Disassembling and installing the electronic module

3.4.3 Replacing a module

Dismounting

- 1 | Remove the wiring from the module, if any. For details refer to section **Wiring**.
- 2 | Unlock the electronic module to its right at the bottom.
- 3 | To remove the electronic module, pull it out towards the front.
- 4 | Flap the locking lever of the module to be replaced upwards.
- 5 | To remove the module, pull it out towards the front.




Fig. 3-12: Disassembling a module

Installing the new module

- 1 | Flap the locking lever of the module upwards.
- 2 | Plug the module in the gap between the modules.
- 3 | Slide the module with the help of the guide strips at both sides onto the DIN rail.
- 4 | Flap the locking lever of the module downwards.
- 5 | Plug in the electronic module.




Fig. 3-13: Installing the new module

3.4.4 Replacing a bus node

Disassembly

**CAUTION!**

Power module and bus interface belong together!

If separated, the modules get destroyed.

→ Do not separate power module and bus interface!

- 1 | Remove the wiring from the bus node, if any. For details, please see section **Wiring**.
- 2 | Unlock the electronic module to its right at the bottom.
- 3 | To remove the electronic module, pull it out towards the front.
- 4 | Flap the locking lever of the bus node upwards.
- 5 | To remove the bus node, pull it out towards the front.




Fig. 3-14: Disassembling the bus node

Installing the new bus node

- 1 | Flap the locking levers of the bus node upwards.
- 2 | Plug the bus node in the left module.
- 3 | Slide the bus node with the help of the guide strips onto the DIN rail.
- 4 | Flap the locking levers downwards.
- 5 | Plug in the electronic module.




Fig. 3-15: Installing the new bus node

3.4.5 Replacing a module group

Disassembly

- 1 | Remove the wiring from the module group, if any. For details, please see section **Wiring**.
- 2 | Unlock the electronic module to its right at the bottom.
- 3 | To remove the electronic module, pull it out towards the front.
- 4 | Flap the locking levers of the module group upwards.
- 5 | To remove the module group, pull it out towards the front.




Fig. 3-16: Disassembling the module group

Installing the new module group

- 1 | Flap the locking levers of the module group upwards.
- 2 | Plug the module group in the gap between the modules.
- 3 | Slide the module group with the help of the guide strips at both sides onto the DIN rail.
- 4 | Flap the locking levers of the module group downwards.
- 5 | Plug in the electronic module.




Fig. 3-17: Mounting of the module group


3.5 Wiring

3.5.1 Spring terminals

Terminals

Spring terminals are used for wiring. Spring terminals allow you to connect the signaling lines and power cables fast and easily. This type of connection is resistant to vibrations.


Cable data

| | |
|---|---|
|  | $U_{\max.}$: 240 V AC / 30 V DC |
| | $I_{\max.}$: 10 A |
| | Cross section: 0.08 ... 1.5 mm ² (AWG 28 ... 16) |
| | Stripping length: 10 mm |

3.5.2 Procedure

Wiring

✂ Tools: suitable screwdriver



✂ Wire cross-section: 0.08 mm² ... 1.5 mm² (AWG 28 ... 16)

- 1 | Put the screwdriver slightly inclined in the rectangular opening (Fig. 3-18: 1).
- 2 | Press and hold the screwdriver away from the round opening. The contact spring is open (Fig. 3-18: 2).
- 3 | Put the stripped wire in the round opening (Fig. 3-18: 2).
- 4 | Remove the screwdriver (Fig. 3-18: 3).

The wire is securely connected with the terminal by means of a spring contact.




Fig. 3-18: Spring terminals

3.5.3 Standard wiring

Standard wiring




Fig. 3-19: Standard wiring

- 1 24 V DC for power supply of I/O level (max. 10 A)
- 2 24 V DC for electronics supply, bus node and I/O level

3.5.4 Fuse protection



WARNING!

The power supply is not protected internally.

It can get destroyed by too high currents.

→ Protect the power supply externally using a fuse or line circuit breaker!



NOTE

The electronics supply is internally protected against too high voltages by means of a fuse. The fuse is located inside the power module. After the fuse has tripped, the electronic module has to be replaced!

External fuse

| | External Fuse | Circuit breaker (optional) | Comment |
|--|---------------|----------------------------|-------------------------|
| Power supply | 10 A (fast) | 10 A characteristic Z | up to max. current 10 A |
| Electronics supply, bus node and I/O level | 2 A (fast) | 2 A characteristic Z | Recommendation! |
| Electronics supply, I/O level, power module art. no. 57131 | 1 A (fast) | 1 A characteristic Z | Recommendation! |

Tab. 3-1: Fuse protection of power supplies

3.5.5 Using power modules

Status of the electronics power supply

After switching on Cube20S, the RUN or MF LED lights up at every module. If the total current for the electronics supply exceeds 3 A, the LEDs are not activated. In this case, plug in the power module, art. no. 57130, between the expansion modules.



NOTE

To guarantee power supply, the power modules can be used in any combination.

Power module art. no. 57130

Use this power module if

- 10 A are not longer enough for power supply
- you want to have groups of different potentials




Fig. 3-20: Power module art. no. 57130

- 1 24 V DC for power supply of I/O level (max. 10 A)
- 2 24 V DC for electronics supply, bus node and I/O level

**Power module art. no.
57131**

Use this power module if 3 A are not enough for electronics supply on backplane bus.

In addition, you will have a new group of potential for 24 V DC power supply with max. 4 A.

Using a power module, you can plug in modules with a maximum total current of 2 A in the following backplane bus. Then you have to plug in another power module.




Fig. 3-21: Power module art. no. 57131

- 1 24 V DC for power supply of I/O level (max. 10 A)
- 2 24 V DC for electronics supply, bus node and I/O level
- 3 24 V DC for power supply of I/O level (max. 4 A)
- 4 24 V DC for electronics supply, I/O level

3.5.6 Fixing the shield



Fixing the shield

NOTE

Shield bus carriers are required for installing a shield (see **Accessories**).




Fig. 3-22: Fixing the shield

- 1 Shield bus carrier
- 2 Shield bus (10 mm x 3 mm)
- 3 Shield terminal block
- 4 Shielding







Fixing the shielding

- ✓ The shield bus carrier and the shield bus have been plugged in.
- ➔ Fasten the lines with the stripped shield.
- ➔ Connect the shield terminal blocks to the shield bus.

3.6 Troubleshooting - LEDs

General information

Each module has two LEDs on the front: **RUN** and **MF**. These LEDs allow you to detect errors in your system or faulty modules.

| Designation | Indication | LED status |
|-------------|---|----------------|
| RUN LED |  | off |
| |  | green |
| |  | flashing green |
| MF LED |  | off |
| |  | red |
| |  | flashing red |


Tab. 3-2: Status indications of the LEDs

Total current of electronics supply exceeded




| | |
|--|---|
| Reaction of the LEDs after switching on: | The RUN LEDs of all modules are off. The MF LEDs are only lighted on some modules. |
| Cause: | The total current for electronics supply exceeds the maximum current. |
| Remedy: | Plug in the power module art. no. 57131. For details, please see section Wiring . |

Configuration error



| | |
|--|---|
| Reaction of the LEDs after switching on: | The RUN LEDs are off on one or several modules. The MF LEDs are flashing on these modules. |
| Cause: | The module on which the MF LED is flashing, does not match the current configuration. |
| Remedy: | Match configuration and hardware structure. |

Module failure



| | |
|--|---|
| Reaction of the LEDs after switching on: | The RUN LEDs are flashing up to the module to the left of the defective module. On the following modules, the RUN LED is off. The MF LEDs are off up to the module to the left of the defective module. On the following modules, the MF LED is lit. |
| Cause: | The module to the right of the flashing modules is defective. |
| Remedy: | Replace the defective module. |

4 Art. no. Counter module 57161 1X32 bits 2 MHz


4.1 Features

Features


- 1 counter 32 bits (AB) invertible, 5 V DC (difference signal)
- Counting frequency max. 2 MHz (AB 1/2/4-fold evaluation or pulse and direction)
- Comparison value, set value, input filter, reset
- Alarm and diagnostic function with μ s time stamp
- μ s time stamp for the counter value (e.g. for speed measurement)











4.2 Design

57161




Status indication



| RUN | MF | Description |
|---|---|---|
|  |  | Bus communication is OK Module status is OK |
|  |  | Bus communication is OK Module status reports error |
|  |  | Bus communication is not possible Module status reports error |
|  |  | Error Bus supply voltage |
|  |  | Configuration error (see 3.6 Troubleshooting - LEDs, Seite 31) |


Tab. 4-1: Status indications of RUN and MF LED

| LED | Color | Description |
|-------|---|----------------------------------|
| A |  | Inputs 1, 5 A / pulse is set |
| B | | Inputs 4, 8 B / direction is set |
| Reset | | Inputs 7, 8 / reset is set |

Tab. 4-2: Status of the inputs and outputs

Terminal

➔ Connect the wires with a cross section from 0.08 mm² to 1.5 mm².



| Pos. | Function | Type | Description |
|------|----------|--------|---|
| 1 | A+ | Input | A / pulse Differential input for count signal or track A of an encoder for 1-, 2- or 4-fold evaluation |
| 2 | 5 V DC | Output | 5 V DC for encoder (max. 500 mA) |
| 3 | 0 V | Output | GND |
| 4 | B+ | Input | B / Direction Differential input for direction signal or track B of an encoder (can be inverted using parameterization) |
| 5 | A | Input | A / pulse Differential input for count signal or track A of an encoder for 1-, 2- or 4-fold evaluation |
| 6 | Z+ | Input | Differential input for reset |
| 7 | Z- | Input | Differential input for reset |
| 8 | B- | Input | B / Direction Differential input for direction signal or track B of an encoder (can be inverted using parameterization) |

Tab. 4-3: Terminal assignment

4.3 Quick start

Counting range

Max. counting frequency:
2 MHz

| Limits | Valid value range |
|-------------------|--------------------------------|
| Lower count limit | -2 147 483 648 (-2^{31}) |
| Upper count limit | +2 147 483 647 ($+2^{31}-1$) |

Tab. 4-4: Counting range

Address ranges

In CPU, PROFIBUS and PROFINET the input and output range is displayed in the corresponding address range.

IX Index for access using CANopen
SX Subindex for access via EtherCAT

Input range 8 byte

| Addr. | Name | Bytes | Function | IX | SX |
|-------|--------|-------|-----------------------|--------|------|
| +0 | CV_I | 4 | Counter value | 0x5400 | 0x01 |
| +4 | CSTS_I | 2 | Counter status | 0x5402 | 0x02 |
| +6 | C_US | 2 | 16 bits μ s value | 0x5403 | 0x03 |

Tab. 4-5: Input range 8 bytes

Output range 10 bytes

| Addr. | Name | Bytes | Function | IX | SX |
|-------|---------|-------|------------------|--------|------|
| +0 | CC_I | 4 | comparison value | 0x5600 | 0x01 |
| +4 | CS_I | 4 | Set value | 0x5601 | 0x02 |
| +8 | CCTRL_I | 2 | Control word | 0x5602 | 0x03 |

Tab. 4-6: Output range 10 bytes

CSTS_I

Counter status

| Bit | Name | Function |
|-----------|---------------|--|
| 0 | STS_SYNC | Reset was active |
| 1 | STS_CTRL_COMP | Is set if the comparison bit is enabled |
| 2 | STS_SW-GATE | Status Software gate (set if SW gate active) |
| 3 | STS_RST | Status of the Reset input |
| 4 | - | reserved |
| 5 | STS_GATE | Status Internal gate (set if Internal gate active) |
| 6 | STS_COMP | Status Comparison bit |
| 7 | STS_C_DN | Status set if counter direction backwards |
| 8 | STS_C_UP | Status set if counter direction forwards |
| 9 | STS_CMP* | Status Comparator is set if the comparison condition is fulfilled. If Comparison never is set, the bit is never set. |
| 10 | STS_END* | Status set if end value has been reached |
| 11 | STS_OFLW* | Status set for overflow |
| 12 | STS_UFLW* | Status set for underflow |
| 13 | STS_ZP* | Status set for zero crossing |
| 14 ... 15 | - | reserved |

Tab. 4-7: Counter status



* The bits remain set, until they are reset with RES_SET (Bit 6 **Control word**).

CCTRL_I
 Control word

| Bit | Name | Function |
|-----------|-----------------|--|
| 0 | CTRL_SYNC_SET | Activates the Reset mode |
| 1 | CTRL_COMP_SET | Releases the Comparison bit |
| 2 | SW_GATE_SET | Sets the software gate |
| 3 ... 4 | - | reserved |
| 5 | COUNTERVAL_SET | Sets the counter temporarily to the value in the set value |
| 6 | RES_SET | Resets the bits with a 0-1 edge: STS_CMP STS_END STS_OFLW STS_UFLW STS_ZP |
| 7 | - | reserved |
| 8 | CTRL_SYNC_RESET | Disables the Reset mode |
| 9 | CTRL_COMP_RESET | Disables the comparison bit |
| 10 | SW_GATE_RESET | Resets the software gate |
| 11 ... 15 | - | reserved |

Tab. 4-8: Control word

Parameterization data

| | |
|----|---|
| DS | Data record for access using CPU, PROFIBUS and PROFINET |
| IX | Index for access using CANopen |
| SX | Subindex for access via EtherCAT |

| Name | Bytes | Function | Default | DS | IX | SX |
|---------|-------|-------------------------|---------|------|-------------------|------|
| DIAG_EN | 1 | Diagnostic interrupt* | 0x00 | 0x00 | 0x3100 | 0x01 |
| CH0A | 1 | Input frequency Track A | 0x02 | 0x01 | 0x3101 | 0x02 |
| CH1B | 1 | Input frequency Track B | 0x02 | 0x01 | 0x3102 | 0x03 |
| CH2R | 1 | Input frequency Reset | 0x02 | 0x01 | 0x3103 | 0x04 |
| CH3 | 1 | reserved | 0x00 | 0x01 | 0x3104 | 0x05 |
| INT_I | 1 | Alarm behavior* | 0x00 | 0x80 | 0x3105 | 0x06 |
| FCT_I | 1 | Counter function* | 0x00 | 0x80 | 0x3106 | 0x07 |
| MODE2_I | 1 | Counter mode 2* | 0x00 | 0x80 | 0x3107 | 0x08 |
| MODE3_I | 1 | Counter mode 3* | 0x00 | 0x80 | 0x3108 | 0x09 |
| END_I | 4 | End value | 0x00 | 0x81 | 0x3109 ... 0x310C | 0x0A |
| LOAD_I | 4 | Load value | 0x00 | 0x81 | 0x310D ... 0x3110 | 0x0B |
| HYST_I | 1 | Hysteresis | 0x00 | 0x81 | 0x3111 | 0x0C |
| CRES | 1 | reserved | 0x00 | 0x81 | 0x3112 | 0x0D |

Tab. 4-9: Parameters



* The parameters DIAG_EN, INT_I, FCT_I, MODE2_I and MODE3_I may only be transmitted in the STOP state.

Controlling the counter

The counter is controlled using the internal gate (I gate). The I gate corresponds to the software gate (SW gate).

| | | |
|----------------|--------------------|--|
| SW gate | Opening (enable): | In the user program using 0-1 edge of SW_GATE_SET in the Control word |
| | Closing (disable): | In the user program using 0-1 edge of SW_GATE_RESET in the control word |

Tab. 4-10: SW gate

Comparison bit

The following behavior can be set for the STS_COMP comparison bit in the counter status using parameterization:

- No comparison: **Comparison bit** is not actuated
- **Counter value** \geq **Comparison value**: **Comparison bit** is set
- **Counter value** \leq **Comparison value**: **Comparison bit** is set
- **Counter value** = **Comparison value**: **Comparison bit** is set



The **comparison bit** is set only if the STS_CTRL_COMP bit is set in the counter status.

4.4 Input/output range

Overview

The following ranges in the input/output range are reserved for the module:

Address ranges

In CPU, PROFIBUS and PROFINET the input and output range is displayed in the corresponding address range.

IX Index for access using CANopen

SX Subindex for access via EtherCAT

Input range 8 byte

| Addr. | Name | Bytes | Function | IX | SX |
|-------|--------|-------|-----------------------|--------|------|
| +0 | CV_I | 4 | Counter value | 0x5400 | 0x01 |
| +4 | CSTS_I | 2 | Counter status | 0x5402 | 0x02 |
| +6 | C_US | 2 | 16 bits μ s value | 0x5403 | 0x03 |

Tab. 4-11: Input range 8 bytes

CV_I
Counter value

The **counter value** always contains the current counter value.

CSTS_I
Counter status

| Bit | Name | Function |
|-----------|---------------|--|
| 0 | STS_SYNC | Reset was active |
| 1 | STS_CTRL_COMP | Is set if the comparison bit is enabled |
| 2 | STS_SW-GATE | Status Software gate (set if SW gate active) |
| 3 | STS_RST | Status of the Reset input |
| 4 | - | reserved |
| 5 | STS_GATE | Status Internal gate (set if Internal gate active) |
| 6 | STS_COMP | Status Comparison bit |
| 7 | STS_C_DN | Status set if counter direction backwards |
| 8 | STS_C_UP | Status set if counter direction forwards |
| 9 | STS_CMP* | Status Comparator is set if the comparison condition is fulfilled. If Comparison never is set, the bit is never set. |
| 10 | STS_END* | Status set if end value has been reached |
| 11 | STS_OFLW* | Status set for overflow |
| 12 | STS_UFLW* | Status set for underflow |
| 13 | STS_ZP* | Status set for zero crossing |
| 14 ... 15 | - | reserved |

Tab. 4-12: Counter status

* The bits remain set, until they are reset with RES_SET (Bit 6 **Control word**).



C_US
 μ s ticker

A timer (μ s ticker) is located in the Cube20S module. It is started with Power-ON and starts with 0 after 65535 μ s.

After every change of the counter value, the time value of the timer is saved as a 16-bit value in μ s together with the counter value in the input range.

Output range 10 bytes

| Addr. | Name | Bytes | Function | IX | SX |
|-------|---------|-------|------------------|--------|------|
| +0 | CC_I | 4 | comparison value | 0x5600 | 0x01 |
| +4 | CS_I | 4 | Set value | 0x5601 | 0x02 |
| +8 | CCTRL_I | 2 | Control word | 0x5602 | 0x03 |

Tab. 4-13: Output range 10 bytes

CC_I
Comparison value

Defining comparison value

- ➔ The behavior of the output is specified by means of the MODE2_I parameter.
- ➔ The behavior of the process interrupt is defined by means of the INT_I parameter.

The comparison value is compared to the current counter value and affects the counter output or triggers a process interrupt.

CS_I
Set value

Loading counter with set value:

- ➔ Specify a set value.

*The set value is accepted in the counter with a 0-1 edge of COUNTERVAL_SET in the **control word**.*

CCTRL_I
Control word

| Bit | Name | Function |
|-----------|-----------------|--|
| 0 | CTRL_SYNC_SET | Activates the Reset mode |
| 1 | CTRL_COMP_SET | Releases the Comparison bit |
| 2 | SW_GATE_SET | Sets the software gate |
| 3 ... 4 | - | reserved |
| 5 | COUNTERVAL_SET | Sets the counter temporarily to the value in the set value |
| 6 | RES_SET | Resets the bits with a 0-1 edge: STS_CMP STS_END STS_OFLW STS_UFLW STS_ZP |
| 7 | - | reserved |
| 8 | CTRL_SYNC_RESET | Disables the Reset mode |
| 9 | CTRL_COMP_RESET | Disables the comparison bit |
| 10 | SW_GATE_RESET | Resets the software gate |
| 11 ... 15 | - | reserved |

Tab. 4-14: Control word

4.5 Parameterization

Overview

Using the parameters, define among other things:

- Alarm behavior
- Input filter
- Counter operating mode or behavior
- Load value and end value

Parameterization data

DS Data record for access using CPU, PROFIBUS and PROFINET
 IX Index for access using CANopen
 SX Subindex for access via EtherCAT

| Name | Bytes | Function | Default | DS | IX | SX |
|---------|-------|-------------------------|---------|------|-------------------|------|
| DIAG_EN | 1 | Diagnostic interrupt* | 0x00 | 0x00 | 0x3100 | 0x01 |
| CH0A | 1 | Input frequency Track A | 0x02 | 0x01 | 0x3101 | 0x02 |
| CH1B | 1 | Input frequency Track B | 0x02 | 0x01 | 0x3102 | 0x03 |
| CH2R | 1 | Input frequency Reset | 0x02 | 0x01 | 0x3103 | 0x04 |
| CH3 | 1 | reserved | 0x00 | 0x01 | 0x3104 | 0x05 |
| INT_I | 1 | Alarm behavior* | 0x00 | 0x80 | 0x3105 | 0x06 |
| FCT_I | 1 | Counter function* | 0x00 | 0x80 | 0x3106 | 0x07 |
| MODE2_I | 1 | Counter mode 2* | 0x00 | 0x80 | 0x3107 | 0x08 |
| MODE3_I | 1 | Counter mode 3* | 0x00 | 0x80 | 0x3108 | 0x09 |
| END_I | 4 | End value | 0x00 | 0x81 | 0x3109 ... 0x310C | 0x0A |
| LOAD_I | 4 | Load value | 0x00 | 0x81 | 0x310D ... 0x3110 | 0x0B |
| HYST_I | 1 | Hysteresis | 0x00 | 0x81 | 0x3111 | 0x0C |
| CRES | 1 | reserved | 0x00 | 0x01 | 0x3112 | 0x0D |

Tab. 4-15: Parameters



* The parameters DIAG_EN, INT_I, FCT_I, MODE2_I and MODE3_I may only be transmitted in the STOP state.

DIAG_EN Diagnostic interrupt

| Byte | Bit 7 ... 0 | Description |
|------|-------------|----------------------|
| 0 | 7 ... 0 | Diagnostic interrupt |
| | | 0x00 disable |
| | | 0x40 enabled |

Tab. 4-16: Diagnostic interrupt

➔ Enable or disable the diagnostic function here.

CHxx Input frequency

| Byte | Function | Possible values |
|------|-------------------------|---------------------------------|
| 0 | Input frequency Track A | 0x00: 500 kHz 0x06: 10 kHz |
| 1 | Input frequency Track B | 0x01: 300 kHz 0x07: 5 kHz |
| 2 | Input frequency Reset | 0x02: 100 kHz 0x08: 2 kHz |
| 3 | reserved | 0x03: 60 kHz 0x09: 1 kHz |
| | | 0x04: 30 kHz |
| | | Other values are not permitted! |

Tab. 4-17: CHxx Input frequency

Defining filters for the inputs of track A, track B and reset

➔ Specify the **input frequency**.

The filter filters out, for example signal peaks for unclear input signal.

INT_I

Alarm behavior

| Byte | Bit 7 ... 0 | Description |
|------|-------------|---|
| 0 | 5 ... 0 | Alarm behavior |
| | | 0 0 (fixed) |
| | | 1 0 (fixed) |
| | | 2 Process interrupt Overflow |
| | | 3 Process interrupt Underflow |
| | | 4 Process interrupt Comparison value |
| | | 5 Process interrupt End value |
| | 7 ... 6 | 0 (fixed) |

Tab. 4-18: Alarm behavior

Activating process interrupt

➔ Set the corresponding bit.

FCT_I

Counter function

| Byte | Bit 7 ... 0 | Description |
|------|-------------|-------------------------------------|
| 0 | 5 ... 0 | Counter function |
| | | 000000b Count continuously |
| | | 000001b Once: forwards |
| | | 000010b Once: backwards |
| | | 000100b Once: no main direction |
| | | 001000b Periodic: forwards |
| | | 010000b Periodic: backwards |
| | | 100000b Periodic: no main direction |
| | 7 ... 6 | 0 (fixed) |

Tab. 4-19: Counter function

MODE2_I

Counter mode 2

| Byte | Bit 7 ... 0 | Description |
|------|-------------|--|
| 0 | 2 ... 0 | Comparison bit is set (... under the following condition) |
| | | 000b Never |
| | | 001b Counter value \geq Comparison value |
| | | 010b Counter value \leq Comparison value |
| | | 100b Counter value = comparison value |
| | 3 | Invert counter direction track B |
| | | 0 No (do not invert) |
| | | 1 Yes (invert) |
| | 6 ... 4 | Reset |
| | | 000b disabled |
| | | 001b High level |
| | | 010b Edge 0-1 |
| | | 100b 0-1 edge once |
| | 7 | 0 (fixed) |

Tab. 4-20: MODE2_I counter mode 2



Actuation of the comparison bit STS_COMP: In the **Control word**, **CTRL_COMP_SET** (bit 1) must be set!

Actuation of the reset: In the **Control word**, **CTRL_SYNC_SET** (bit 0) must be set!

MODE3_I
Counter mode 3

| Byte | Bit 7 ... 0 | Description |
|------|-------------|--|
| 0 | 2 ... 0 | Signal evaluation |
| | | 000b Counter disabled |
| | | 001b Rotary encoder 1-fold (to A and B) |
| | | 010b Rotary encoder 2-fold (to A and B) |
| | | 011b Rotary encoder 4-fold (to A and B) |
| | | 100b Direction (pulse to A and direction to B) |
| | 6 ... 3 | 0 (fixed) |
| | 7 | Gate function (internal gate) |
| | | 0 Cancel |
| | | 1 Interrupt |

Tab. 4-21: Counter mode 3



Counter disabled: Further parameter specifications for the counter are ignored.

Cancel gate function: The counting process is continued again starting from the load value.

Interrupt gate function: The counting process is continued from the counter value.

END_I, LOAD_I
 End value, load value

Limiting the lower counting range:

➔ Enter a **load value** LOAD_I.

Limiting the upper counting range:

➔ Enter an **end value** END_I.

HYST_I
 Hysteresis

If the **counter value** is within the range of the **comparison value**, the **hysteresis** avoids frequent switching of the **comparison bit** and alarm.

Defining hysteresis between 0 and 255

➔ 0 or 1: Switching off hysteresis

➔ Value between 2 and 255: Switch on **hysteresis range**

The **Hysteresis** influences the zero crossing, comparison, overflow and underflow.

4.6 Counter functions

Overview

The counter counts forwards and backwards. You can select from the following counter functions:

- Count continuously, for example for distance measurement with incremental encoders
- Count once, for example for unit decoding up to a maximum limit
- Periodical count, for example for applications with repeated counting operations

In the operation modes **Count once** and **Periodical count** define a counter range as the start or end value using parameterization.

Programmable additional functions are available for the counter, for example gate function, comparison, hysteresis and process interrupt.

Main counting direction

Define the main counting direction for the counter using parameterization.

If **no** main counting direction has been selected, the entire counting range is available:

| Limits | Valid value range |
|-------------------|-------------------------------|
| Lower count limit | -2 147 483 648 (-2^{31}) |
| Upper count limit | +2 147 483 647 ($2^{31}-1$) |

Tab. 4-22: Counting range

Main counting direction

Sets the upper limit of the counting range.

The counter counts from 0 or **load value** in the positive direction up to the configured **end value** -1 and then jumps with the subsequent encoder pulse again to the **load value**.

Main counting direction backwards

Sets the lower limit of the counting range.

The counter counts from the configured start value or **load value** in the negative direction up to the configured **end value** +1 and then jumps with the subsequent encoder pulse again to the start value.

Gate function

Abort/Interrupt

If the HW gate is enabled, the gate functions affect only the HW gate. Opening and closing of the SW gate affects only in an interrupting manner.

Aborting counting

The counting process starts with the **load value** after closing and restarting the gate.

Interrupting counting

The counting is continued with the last current counter value after closing and restarting the gate.

Counting continuously

In this operating mode the counter counts starting with the **load value**.

If the counter reaches the upper count limit during up-counting and another counting pulse in the positive direction is received, it jumps to the lower count limit and continues counting from there.

If the counter reaches the lower count limit during down-counting and another counting pulse in the negative direction is received, it jumps to the upper count limit and continues counting from there.

The count limits are set fixedly to the maximum counting range.

| Limits | Valid value range |
|-------------------|-------------------------------|
| Lower count limit | -2 147 483 648 (-2^{31}) |
| Upper count limit | +2 147 483 647 ($2^{31}-1$) |

Tab. 4-23: Counting range



If the count limit is exceeded or not reached, the status bits STS_OFLW or STS_UFLW are set.

The bits remain set until they are reset again using the RES_SET in the **control word**.

If enabled, a process interrupt is triggered additionally.




Fig. 4-1: Operating mode **Count continuously**



Counting once

No main counting direction

- The counter counts once starting with the **load value**.
- The counter counts forwards or backwards.
- The count limits are set fixedly to the maximum counting range.
- In case of overflow or underflow at the count limits, the counter jumps to the opposite count limit correspondingly, the internal gate is closed automatically and the status bits STS_OFLW or STS_UFLW are set. If enabled, a process interrupt is triggered additionally.
- To restart counting you have to open the internal gate again.
- With the interrupting gate control, the counting process is continued starting from the current **counter value**.
- In case of aborting gate control, the counter starts with the **load value**.

| Limits | Valid value range |
|-------------------|-------------------------------|
| Lower count limit | -2 147 483 648 (-2^{31}) |
| Upper count limit | +2 147 483 647 ($2^{31}-1$) |

Tab. 4-24: Counting range


Fig. 4-2: Operating mode **Count once (interrupting gate control)**Fig. 4-3: Operating mode **Count once (aborting gate control)**

Main counting direction

- The counter counts forwards starting with the **load value**.
- If the counter reaches the **end value** -1 in the positive direction, it jumps after the next counter pulse to the **load value** and the internal gate is closed automatically. If enabled, a process interrupt is triggered additionally.
- To restart counting you have to open the internal gate again. The counter starts with the **load value**.
- The counter counts beyond the lower count limit.

| Limits | Valid value range |
|-------------------|--|
| End value | -2 147 483 647 ($-2^{31}+1$) ... +2 147 483 647 ($2^{31}-1$) |
| Lower count limit | -2 147 483 648 (-2^{31}) |

Tab. 4-25: Counting range


Fig. 4-4: Operating mode **Count once** (main counting direction forwards)

Main counting direction backwards

- The counter counts backwards starting from the **load value**.
- If the counter reaches the **end value +1** in the negative direction, it jumps after the next counter pulse to the **load value** and the internal gate is closed automatically. If enabled, a process interrupt is triggered additionally.
- To restart counting you have to open the internal gate again. The counter starts with the **load value**.
- The counter counts beyond the upper count limit.

| Limits | Valid value range |
|-------------------|--|
| End value | $-2\,147\,483\,648\,(-2^{31}) \dots +2\,147\,483\,646\,(2^{31}-2)$ |
| Upper count limit | $2\,147\,483\,647\,(2^{31}-1)$ |

Tab. 4-26: Counting range

Fig. 4-5: Operating mode **Count once (main counting direction backwards)**


Periodical count

No main counting direction

- The counter counts from the **load value** forwards or backwards.
- In case of overflow or underflow at the corresponding count limit, the counter jumps to the **load value** and continues counting from there. If enabled, a process interrupt is triggered additionally.
- The count limits are set fixedly to the maximum counting range.

| Limits | Valid value range |
|-------------------|-------------------------------|
| Lower count limit | -2 147 483 648 (-2^{31}) |
| Upper count limit | +2 147 483 647 ($2^{31}-1$) |

Tab. 4-27: Counting range


Fig. 4-6: Operating mode **Periodical count (no main counting direction)**

Main counting direction

- The counter counts forwards starting with the **load value**.
- If the counter reaches the **end value** -1 in the positive direction, it jumps after the next counter pulse to the **load value** and the internal gate is closed automatically. If enabled, a process interrupt is triggered additionally.
- The counter counts beyond the lower count limit.

| Limits | Valid value range |
|-------------------|--|
| End value | $-2\,147\,483\,647 (-2^{31}+1) \dots +2\,147\,483\,647 (2^{31}-1)$ |
| Lower count limit | $-2\,147\,483\,648 (-2^{31})$ |

Tab. 4-28: Counting range


Fig. 4-7: Operating mode **Periodical count** (main counting direction forwards)

Main counting direction backwards

- The counter counts backwards starting from the **load value**.
- If the counter reaches the **end value** +1 in the negative direction, it jumps after the next counter pulse to the **load value** and the internal gate is closed automatically. If enabled, a process interrupt is triggered additionally.
- The counter counts beyond the upper count limit.

| Limits | Valid value range |
|-------------------|--|
| End value | $-2\,147\,483\,648 (-2^{31}) \dots +2\,147\,483\,646 (2^{31}-2)$ |
| Upper count limit | $2\,147\,483\,647 (2^{31}-1)$ |

Tab. 4-29: Counting range

Fig. 4-8: Operating mode **Periodical count (main counting direction backwards)**

4.7 Additional functions Counter

Overview

The additional functions can be set using parameterization.

■ Gate function

The gate function starts, stops and interrupts a counting function.

■ Comparison

Here you enter a **comparison value** which enables the digital output depending on the **counter value** or triggers a process interrupt.

■ Hysteresis

Specification of a **hysteresis** prevents, for example constant triggering of the alarms if the value of an encoder signal fluctuates around the **comparison value**.

Schematic Design

The figure shows how the additional functions affect the counting behavior. These additional functions are explained in detail on the following pages:




Fig. 4-9: Schematic view

Gate function

- ➔ You enable or disable the counter by means of an internal gate (I gate). The I gate corresponds to the software gate (SW gate).
- ➔ You can open (enable) the **SW gate** in the user program using a 0-1 edge at bit SW_GATE_SET in the **output range** in the **control word**.
- ➔ Use a 0-1 edge at bit SW_GATE_RESET to close (disable) the **SW gate** again.
- ➔ If the I gate is closed automatically during **Count once**, it can be opened again only by means of an edge 0-1 at SW_GATE_SET.

The following conditions influence the **I gate**.

| SW gate | influences the I gate |
|---------------|-----------------------|
| 0 | 0 |
| 1 | 1 |
| with 0-1 edge | 1 |

Tab. 4-30: Gate function

Aborting and interrupting gate functions

Using the parameterization, define whether the gate aborts or interrupts the counting process.

- With the **aborting gate function**, the counting process starts with the **load value** after the gate restart.




Fig. 4-10: Aborting gate function

- With the **interrupting gate function**, the counting is continued after the gate start at the current **counter value**.




Fig. 4-11: Interrupting gate function

Comparison function



Define the **comparison value** using the **output range**. The **comparison bit** can be found in the **counter status** under STS_COMP.

The STS_COMP bit can only be set if the STS_CTRL_COMP bit is set in the **counter status**

The following behavior can be set for the comparison bit using parameterization:

- No comparison: Comparison bit is not affected.
- **Counter value** \geq **Comparison value**: **Comparison bit** is set.
- **Counter value** \leq **Comparison value**: **Comparison bit** is set.
- **Counter value** = **Comparison value**: **Comparison bit** is set

No comparison

The **comparison bit** is not affected.

The comparison bit is set if the counter value \geq Comparison value

As long as the **counter value** is higher or equal to the **comparison value**, the **comparison bit** remains set.

The comparison bit is set if the counter value \leq Comparison value

As long as the **counter value** is smaller or equal to the **comparison value**, the **comparison bit** remains set.

The comparison bit is set if the counter value = comparison value

As long as the **counter value** is equal to the **comparison value**, the **comparison bit** is set. The bit remains set until the comparison conditions are no longer fulfilled.

If you have set the main counting direction, the comparison bit is set only after the comparison value from the main counting direction has been reached.



NOTE

Together with the STS_COMP bit, the STS_CMP bit is set in the counter status. Unlike STS_COMP bit, it remains set until it is reset using RES_SET in the **control word**.

Hysteresis

If the counter value is within the range of the comparison value, the **hysteresis** avoids frequent triggering of the alarm.

Defining hysteresis between 0 and 255

- ➔ 0 or 1: Switching off hysteresis
- ➔ Value between 2 and 255: Activate hysteresis range

The **Hysteresis** influences the zero crossing, comparison, overflow and underflow.



An active **hysteresis** remains active after changing.
The new hysteresis range is activated during the next hysteresis event.

The following figures show the behavior of the output with hysteresis 0 and hysteresis 3 for the corresponding conditions.

Mode of action with counter value \geq comparison value




Fig. 4-12: Mode of action

| | | |
|---|---|---|
| 1 | Counter value \geq Comparison value | Comparison bit is set and hysteresis is activated |
| 2 | Leaving the hysteresis range | Comparison bit is reset |
| 3 | Counter value \geq Comparison value | Comparison bit is set and hysteresis is activated |
| 4 | Leaving the hysteresis range and counter value \geq Comparison value | Comparison bit remains set |
| 5 | Counter value $<$ comparison value and hysteresis active | Comparison bit is reset |
| 6 | Counter value \geq Comparison value and hysteresis activated | Comparison bit is not set |
| 7 | Leaving the hysteresis range and counter value \geq Comparison value | Comparison bit is set |



Once the comparison condition has been reached, the **hysteresis** is activated. With the activated **hysteresis**, the comparison result remains unchanged until the **counter value** leaves the set hysteresis range.
After leaving the hysteresis range, the **hysteresis** is activated again only if the comparison conditions are reached.

Mode of action with counter value = comparison value




Fig. 4-13: Mode of action

| | | |
|---|--|--|
| 1 | Counter value = comparison value | Comparison bit is set and hysteresis is activated |
| 2 | Leaving the hysteresis range | The comparison bit is reset and counter value < comparison value |
| 3 | Counter value = comparison value | Comparison bit is set and hysteresis is activated |
| 4 | Leaving the hysteresis range and counter value > comparison value | Comparison bit is reset |
| 5 | Counter value = comparison value | Comparison bit is reset and hysteresis is activated |
| 6 | Counter value = comparison value and hysteresis active | Comparison bit remains set |
| 7 | Leaving the hysteresis range and counter value > comparison value | Comparison bit is reset |



Once the comparison condition has been reached, the ***hysteresis*** is activated. With the activated ***hysteresis***, the comparison result remains unchanged until the ***counter value*** leaves the set hysteresis range. After leaving the hysteresis range, the ***hysteresis*** is activated again only if the comparison conditions are reached.

4.8 Diagnosis and interrupt

Overview

| Trigger | Process interrupt | Diagnostic interrupt | programmable |
|-------------------------------------|-------------------|----------------------|--------------|
| Overflow | x | - | x |
| Underflow | x | - | x |
| Comparison value | x | - | x |
| End value | x | - | x |
| Diagnostic buffer overflow | - | x | - |
| Process interrupt lost | - | x | - |
| External supply voltage is missing* | - | x | x |

Tab. 4-31: Alarm overview



The module triggers an alarm only if the diagnostic interrupt has already been enabled at the time of the supply voltage failure.

If the supply voltage is missing already during start-up (diagnostic interrupt disabled), no diagnostic interrupt is reported.

Process interrupt data

Activate the process interrupts in order to respond to asynchronous events. A process interrupt stops the linear program sequence and branches depending on the master system into a certain interrupt routine. Here you can respond to the process interrupt.

CANopen transmits the process interrupt data in an Emergency telegram.

If CPU, PROFIBUS and PROFINET are used for access, they transmit this process interrupt data in a diagnosis telegram.

SX = Subindex for access via EtherCAT.

| Name | Bytes | Function | Default | SX |
|---------|-------|------------------------|---------|---------------|
| PRIT_A | 1 | Process interrupt data | 0x00 | 0x02 |
| PRIT_B | 1 | Status of the inputs | 0x00 | 0x03 |
| PRIT_US | 2 | µs ticker | 0x00 | 0x04 ... 0x05 |

Tab. 4-32: Process interrupts

PRIT_A Process interrupt data

| Byte | Bit 7 ... 0 | Description |
|------|-------------|--|
| 0 | | Process interrupt data |
| | 1 ... 0 | reserved |
| | 2 | Overflow, underflow or end value reached |
| | 3 | Comparison value reached |
| | 7 ... 4 | reserved |

Tab. 4-33: Process interrupt data

PRIT_B Status of the inputs

| Byte | Bit 7 ... 0 | Description |
|------|-------------|--|
| 0 | | Status of the inputs at the moment of process interrupt |
| | 0 | Input value channel 0 (track A) |
| | 1 | Input value channel 1 (track B) |
| | 2 | Input value channel 2 (reset) |
| | 7 ... 3 | reserved |

Tab. 4-34: Status of the inputs

PRIT_US
 µs ticker

| Byte | Bit 7 ... 0 | Description |
|---------|-------------|---|
| 0 ... 1 | | Value of the µs ticker at the moment of the process interrupt |

Tab. 4-35: µs ticker

Diagnostic data

Using Parameterization activate a diagnostic interrupt for the module.

Function

- Upon triggering of a diagnostic interrupt, the module provides incoming diagnosis data for diagnosis.
- As soon as the reasons for triggering of a diagnosis interrupt are no longer present, you receive an outgoing diagnostic interrupt automatically.
- If an incoming diagnostic interrupt has been triggered for a channel due to Process interrupt lost, all events up to a certain outgoing diagnostic interrupt will be lost.
- The MF-LED of the module is lit during this period (from the 1st incoming diagnostic interrupt until the last outgoing diagnostic interrupt).

 DS Data record for access using CPU, PROFIBUS and PROFINET
 Access using DS 0x01
 Besides, you can access the first 4 bytes using DS 0x00.

 IX Index for access using CANopen
 Access using IX 0x2F01.
 Besides, you can access the first 4 Bytes using IX 0x2F00

SX Subindex for access via EtherCAT

| Name | Bytes | Function | Default | DS | IX | SX |
|-------------------|-------|------------------------------------|---------|------|--------|---------------|
| ERR_A | 1 | Diagnostics | 0x00 | 0x01 | 0x2F01 | 0x02 |
| MODTYP | 1 | Module information | 0x18 | | | 0x03 |
| ERR_C | 1 | reserved | 0x00 | | | 0x04 |
| ERR_D | 1 | Diagnostics | 0x00 | | | 0x05 |
| CHTYP | 1 | Channel type | 0x76 | | | 0x06 |
| NUMBIT | 1 | No. of diagnostic bits per channel | 0x08 | | | 0x07 |
| NUMCH | 1 | Number of channels of the module | 0x01 | | | 0x08 |
| CHERR | 1 | Channel error | 0x00 | | | 0x09 |
| CH0ERR | 1 | Channel-specific error | 0x00 | | | 0x0A |
| CH1ERR ... CH7ERR | 7 | reserved | 0x00 | | | 0x0B ... 0x11 |
| DIAG_US | 4 | µs ticker | 0x00 | | | 0x12 |

Tab. 4-36: Diagnostic data

 ERR_A
 Diagnostics

| Byte | Bit 7 ... 0 | Description |
|------|-------------|---|
| 0 | Bit 0 | set in case of Assembly fault |
| | Bit 1 | reserved |
| | Bit 2 | set in case of External error |
| | Bit 3 | set in case of Channel error available |
| | Bit 7 ... 4 | reserved |

 MODTYP
 Module information

| Byte | Bit 7 ... 0 | Description |
|------|-------------|---|
| 0 | 3 ... 0 | Module class 1000b Function module |
| | 4 | set if Channel information available |
| | 7 ... 5 | reserved |

Tab. 4-37: Module information

ERR_C
reserved

| Byte | Bit 7 ... 0 | Description |
|------|-------------|-------------|
| 0 | | reserved |

Tab. 4-38: ERR_C

ERR_D
Diagnosis

| Byte | Bit 7 ... 0 | Description |
|------|-------------|--|
| 0 | 2 ... 0 | reserved |
| | 3 | set in case of Internal diagnosis buffer overflow |
| | 5 ... 4 | reserved |
| | 6 | Process interrupt lost |
| | 7 | reserved |

Tab. 4-39: Diagnosis

CHTYP
Channel type

| Byte | Bit 7 ... 0 | Description |
|------|-------------|-------------------------------------|
| 0 | 6 ... 0 | Channel type 0x76 Counter module |
| | 7 | reserved |

Tab. 4-40: Channel type

NUMBIT
Diagnostic bits

| Byte | Bit 7 ... 0 | Description |
|------|-------------|---|
| 0 | 7 ... 0 | Number of diagnostic bits of the module per channel (here 0x08) |

Tab. 4-41: Diagnostic bits

NUMCH
Channels

| Byte | Bit 7 ... 0 | Description |
|------|-------------|--|
| 0 | 7 ... 0 | Number of channels of a module (here 0x01) |

Tab. 4-42: Channels

CHERR
Channel error

| Byte | Bit 7 ... 0 | Description |
|------|-------------|---|
| 0 | 0 | set in case of error of channel group 0 |
| | 7 ... 1 | reserved |

Tab. 4-43: Channel error

CH0ERR
Channel-specific diagnostics

| Byte | Bit 7 ... 0 | Description |
|------|-------------|---|
| 0 | | Diagnostic interrupt due to process interrupt lost at ... |
| | 1 ... 0 | reserved |
| | 2 | Overflow, underflow or end value |
| | 3 | Comparison value reached |
| | 7 ... 4 | reserved |

Tab. 4-44: Channel-specific diagnostics

CH1ERR ...
CH7ERR
reserved

| Byte | Bit 7 ... 0 | Description |
|------|-------------|-------------|
| 0 | | reserved |

Tab. 4-45: CH1ERR ... CH7ERR

DIAG_US
µs ticker

| Byte | Bit 7 ... 0 | Description |
|---------|-------------|--|
| 0 ... 3 | 7 ... 0 | Value of the µs ticker when generating diagnostic data |

Tab. 4-46: µs ticker

5 General data

| Conformity | | | |
|--------------------------------|-----------------------------------|----------------------|---|
| | CE | 2004/108/EC | EMC Directive |
| | | 2011/65/EU | RoHS |
| Personal and device protection | | | |
| | Ingress protection | EN 60529 | IP20 |
| | Electric isolation | | |
| | To fieldbus | - | DC-isolated |
| | To process level | - | DC-isolated |
| | Dielectric strength | EN 61131-2 | - |
| | Insulation voltage to ground | | |
| | Inputs / outputs | - | 50 V AC/DC, with test voltage 500 V AC |
| | Protective measures | - | against short-circuit |
| Ambient conditions | | | |
| | Climatic | | |
| | Storage / transport | EN 60068-2-14 | -25 ... +70 °C |
| | Operation | | |
| | Horizontal installation | EN 61131-2 | 0 ... +60 °C |
| | Vertical installation | EN 61131-2 | 0 ... +60 °C |
| | Humidity | EN 60068-2-30 | RH1 (without condensation, relative humidity 10 ... 95 %) |
| | Pollution | EN 61131-2 | Pollution degree 2 |
| | Mechanical | | |
| | Vibration | EN 60068-2-6 | 1 g, 9 Hz ... 150 Hz |
| Shock | EN 60068-2-27 | 15 g, 11 ms | |
| Installation conditions | | | |
| | Place of installation | - | Inside the switch cabinet |
| | Installation position | - | Horizontal and vertical |
| | Fastening | - | 35 mm DIN rail |
| Mechanical data | | Housing | |
| | Material | PPE / PPE GF10 | |
| | Dimensions (W x H x D) | 12.9 x 109 x 76.5 mm | |
| | Weight | 60 g | |
| Ambient conditions | | | |
| | Operating temperature | 0 °C to 60 °C | |
| | Storage temperature | -25 °C to 70 °C | |
| Certifications | | | |
| | Certification according to UL 508 | | yes |

| EMC / Standard | | | Notes |
|----------------|----------------------|--------------|--|
| | Emitted interference | EN 61000-6-4 | Class A (industrial environments) |
| | Immunity Zone B | EN 61000-6-2 | Industrial environments |
| | | EN 61000-4-2 | ESD 8 kV with air discharge (severity grade 3), 4 kV with contact discharge (severity grade 2) |
| | | EN 61000-4-3 | HF irradiation (housing) 80 MHz ... 1000 MHz, 10 V/m, 80 % AM (1 kHz) 1.4 GHz ... 2.0 GHz, 3 V/m, 80 % AM (1 kHz) 2 GHz ... 2.7 GHz, 1 V/m, 80 % AM (1 kHz) |
| | | EN 61000-4-6 | conducted 150 kHz ... 80 MHz, 10 V, 80 % AM (1 kHz) |
| | | EN 61000-4-4 | Burst, severity grade 3 |
| | | EN 61000-4-5 | Surge, installation class 3 *) |

*) Due to single high-energy impulses, a suitable external wiring with lightning protection elements is required for surge, e.g. lightning arresters and surge arrester.

6 Technical data

| Power consumption / power dissipation | | |
|---------------------------------------|--|---------------------------|
| | Power consumption from the backplane bus | 70 mA |
| | Power dissipation | 0.85 W |
| Digital inputs | | |
| | Number of inputs | - |
| | Cable length shielded | 100 m |
| | Cable length unshielded | - |
| | Nominal load voltage | 20.4...28.8 V DC |
| | Reverse polarity protection of the nominal load voltage | - |
| | Power consumption from load voltage L+ (without load) | 20 mA |
| | Nominal value | - |
| | Input voltage for signal "0" | Differential signal RS422 |
| | Input voltage for signal "1" | Differential signal RS422 |
| | Frequency range | - |
| | Input resistance | 120 Ω |
| | Input current for signal "1" | - |
| | Connection of 2-wire BEROs possible | - |
| | max. permitted BERO quiescent current | - |
| | Input delay of "0" after "1" | 0.8 μ s |
| | Input delay of "1" after "0" | 0.8 μ s |
| | Number of inputs in horizontal installation that can be used simultaneously | - |
| | Number of inputs in vertical installation that can be used simultaneously | - |
| | Input characteristic | - |
| | Input data size | 8 byte |
| Digital outputs | | |
| | Number of outputs | - |
| | Cable length shielded | - |
| | Cable length unshielded | - |
| | Nominal load voltage | - |
| | Power consumption from load voltage L+ (without load) | - |
| | Output delay from "0" to "1" | - |
| | Output delay from "1" to "0" | - |
| | Minimum load current | - |
| | Lamp load | - |
| | Parallel connection of outputs for the redundant actuation | - |
| | Parallel connection of outputs for the redundant actuation to increase the output capacity | - |
| | Actuation of a digital input | - |
| | Switching frequency with resistive load | - |
| | Switching frequency with inductive load | - |
| | Switching frequency with lamp load | - |
| | Limiting (internal) of inductive interrupt voltage | - |
| | Short-circuit protection of the output | - |
| | Response threshold of the protection | - |
| | Number of operating cycles of the relay outputs | - |
| | Switching capacity of the relay contacts | - |
| | Output data size | 10 bytes |

| Counter | | |
|--------------------------|--|-------------------|
| | Number of counters | 1 |
| | Counter width | 32 bits |
| | Maximum input frequency | 500 kHz |
| | Maximum counting frequency | 2 MHz |
| | Operating mode Incremental encoder | yes |
| | Operating mode Pulse/Direction | yes |
| | Operating mode Pulse | - |
| | Operating mode Frequency measurement | - |
| | Operating mode Period duration measurement | - |
| | Gate connection possible | - |
| | Latch connection possible | - |
| | Reset connection possible | yes |
| | Counter output possible | - |
| Status, alarm, diagnosis | | |
| | Status indication | yes |
| | Alarms | yes, programmable |
| | Process alarm | yes, programmable |
| | Diagnostic interrupt | yes, programmable |
| | Diagnostic function | yes, programmable |
| | Diagnosis information readable | possible |
| | Module status | Green LED |
| | Module error | Red LED |
| | Channel error | none |
| Electrical isolation | | |
| | between the channels | - |
| | between the channels in groups of | - |
| | between the channels and backplane bus | yes |
| | between the channels and power supply | - |
| | max. potential difference between the circuits | - |
| | max. potential difference between the inputs (U _{cm}) | - |
| | max. potential difference between Mana and Mintern (U _{iso}) | - |
| | max. potential difference between the inputs and Mana (U _{cm}) | - |
| | max. potential difference between the inputs and Mintern (U _{iso}) | - |
| | max. potential difference between Mintern and outputs | - |
| | Insulation tested with | 500 V DC |
| Data sizes | | |
| | Input bytes | 8 |
| | Output bytes | 10 |
| | Parameter bytes | 23 |
| | Diagnostic bytes | 20 |

7 Annex

7.1 Accessories

Bus cover
Art. no. 57190



Fig. 7-1: Bus cover

Carrier for shield busses



The shield busses (10 mm x 3 mm) to connect cable shields are fastened on the carrier.

NOTE

Carriers for shield busses, shield busses and cable shield fasteners are not included in the delivery.

Installing the carrier

- ✓ Prerequisite: The Cube20S system has been completely mounted.
- ➔ If the DIN rail is flat, break the spacer off the carrier.
- ➔ Plug the carrier in the terminal module below the terminal block until it engages.




Fig. 7-2: Installing the carriers for shield busses

7.2 Glossary

General terms:

| Term | Meaning |
|-----------------------|--|
| Intended purpose | Use of a product, process, or feature according to the specifications, instructions, and information supplied by the MANUFACTURER. |
| Bit | Binary digit |
| Byte | 1 byte corresponds to 8 bit |
| DI | Digital inputs |
| DIN | Deutsches Institut für Normung (German Institute for Standardization) |
| I/O | Input/Output |
| Directive 2004/108/CE | EMC Directive |
| EMC | Electromagnetic compatibility |
| EN | European standard |
| ESD | Electrostatic discharges |
| FE | Functional earth |
| I | Current |
| IEC | International Electrotechnical Commission, international standardization institute |
| IN | Input |
| IP20 | Ingress Protection, protection class according to DIN EN 60529 1st code digit = Protection against accidental contact and solid foreign objects 2nd code digit = Protection against ingress of water 2: protected against: solid foreign objects with diameter starting from 12.5 mm and contact with a finger. 0: No protection |
| IP67 | 6: Dustproof, protection against contact with a wire 7: Protection against the effects of temporary submersion in water |
| ISO | International Standard Organization |
| LED | Light Emitting Diode |
| n. c. | not connected |
| OUT | Output |
| PELV | Protective Extra Low Voltage |
| SELV | Safety Extra Low Voltage |
| U | Voltage |
| U/I | Voltage / current |

7.3 Legal information

Exclusion of liability

Murrelektronik GmbH checked the contents of this technical documentation for conformity with the described hardware and software. Changes on an individual case basis cannot be excluded. For this reason, we shall not assume any responsibility for errors or omissions, in particular for a complete conformity. This exclusion of liability shall not apply in case the damage is caused deliberately and/or due to gross negligence as well as for all claims based on the German Product Liability Act. Should a major contractual obligation negligently be violated, the liability of Murrelektronik GmbH shall be limited to damages that typically arise.

Subject to technical modifications or changes with regard to contents. We recommend to regularly check whether this documentation has been updated because corrections that might be required due to technical modifications will be included by Murrelektronik GmbH at regular intervals. We are always grateful for any proposals of improvement.

Copyright

It is prohibited to transfer or photocopy the documentation either in paper or in digital form, reuse or divulge its contents unless otherwise expressly permitted by Murrelektronik GmbH or in conjunction with the production of documentation for third-party products that contain products made by Murrelektronik GmbH. Any violation of this provision will result in liability for damage. All rights reserved, in particular in the event of the award of patents or registration of utility models.

Rights of use

Murrelektronik GmbH grants its customers a non-exclusive right revocable at any time and for an indefinite period of time to use this technical documentation to produce their own technical documentation. For this purpose, the documentation produced by Murrelektronik GmbH may be changed in parts, or amended, or copied, and transferred to the customer's users as part of the customer's own technical documentation on paper or on electronic media. In this case, the customers shall bear sole responsibility for the correctness of the contents of the technical documentation produced by them.

If the technical documentation is integrated in part, or in full in the customer's technical documentation, the customer shall refer to the copyright of Murrelektronik GmbH. Furthermore, special attention shall

be paid to compliance with the safety instructions.

Although the customers are obliged to make reference to the copyright of Murrelektronik GmbH, provided the technical documentation of Murrelektronik GmbH is used, the customers shall market and/or use the technical documentation on their sole responsibility. The reason is that Murrelektronik GmbH has no influence on changes or applications of the technical documentation and even minor changes to the starting product or deviations in the intended applications may render incorrect the specifications contained in the technical documentation. For this reason, the customers are obliged to identify the technical documentation originating from Murrelektronik GmbH if and inasmuch as the documentation is changed by the customers. The customers shall undertake to exempt Murrelektronik from the damage claims of third parties if the latter are attributable to any deficits in the documentation. This shall not apply to damages to the rights of third parties caused deliberately or by gross negligence.

The customers shall be entitled to use the company brands of Murrelektronik GmbH exclusively for their product advertising, but only inasmuch as the products of Murrelektronik GmbH are integrated in the products marketed by the customers. When using Murrelektronik GmbH brands, the customers shall mention this in an adequate manner.



Murrelektronik GmbH | Falkenstraße 3, D-71570 Oppenweiler
☎ +49 7191 47-0 | 📠 +49 7191 47-491 000 | info@murrelektronik.com
www.murrelektronik.com

The information in this manual has been compiled with the utmost care. Liability for the correctness, completeness and topicality of the information is restricted to gross negligence.