# Enable/Disable Page Menu Options in DESIGNER.INI

When the Designer program is installed the default settings for the Page Menu Options will be enabled. If you wish to disable any or all of these options, you will need to use a text editor (such as Window's Notepad) to edit the DESIGNER.INI file. The DESIGNER.INI file is located in the Windows directory.

Using a text editor, open the DESIGNER.INI file and scroll down to the [Designer] section. You should see the following text:

```
[Designer]
Toolbelt=1
Statusbar=1
ZoomSize=2
GridMode=1

; ****Page Menu Options*****
; 1 == disable menu option. 0 == enable menu option.
; Option 1 == Delete Page, Option 2 == Insert Page, Option 3 == Append Page

PageOptions=0,0,0

LastFile=
TargetLib=UPLC7.DLL
ApplPath1=A:\MMI1.PRJ
ApplPath2=A:\AZAD.PRJ
ApplPath3=C:\DES404\TESTPRJ\TESTER23.PRJ

[Communications]
CommPort=2
BaudRate=9600
Parity=None
StopBit=1
DataBits=8
StopBits=1
```

The Page Menu Options are defined in the section which is highlighted above. When the Designer program is installed, these options are enabled by default. However, the programmer may disable these features of the Designer by changing the 0's (zero's) to 1's (ones). The first digit after the equal sign enables or disables the Delete Page feature, the second digit controls the Insert Page feature, and the third digit controls the Append Page feature.

## Example:

Lets say the programmer wants to disable the Delete Page option and the Insert Page option, but leave the Append Page option enabled.

Simply change the following line

**PageOption=0,0,0**

to

**PageOption=1,1,0**

and save the file. You must restart Designer for the changes to become effective.

*Technical assistance may be obtained :*
*In North America EXOR at 1-513-874-4665*
*In Europe EXOR Italy 045 - 8779068*