Using UniOP with Allen Bradley's Micrologix PLC

When working with the Micrologix PLC, the user cannot directly access timers or counters using the Designer for Windows software. To access timers and counters, the user needs to:

1. Work with another memory location in the PLC.
2. Within the PLC ladder logic, use a move statement to transfer the contents of the memory location used in step 1 into the memory location of the timer or counter.

Technical assistance may be obtained :
In North America EXOR at 1 -513-874-4665
In Europe EXOR Italy at +39 045 - 8779068