Updating the PLC Support Libraries Manually

The Designer for Windows software package includes the drivers for the numerous PLCs that it supports. It occasionally becomes necessary to update a driver (all of the drivers are available on our BBS). The following steps illustrate the procedure for manually updating an existing driver.

STEP 1 Insert the disk containing the new driver in drive A.

STEP 2 Each driver is named UPLCXXX.DLL, where the XXX will be an integer value. To overwrite the older driver(s) in your Designer directory with the new driver(s), type:

COPY A:\UPLC*.DLL C:\DESIGNER

STEP 3 Restart the Designer for Windows software package.

STEP 4 Select *Project - Change Controller Driver* and click on the *Find All* button. The new version(s) of the driver(s) should appear in the display window.

Technical assistance may be obtained :
In North America EXOR at 1-513-874-4665
In Europe EXOR Italy at +39 045 - 8779068