Pinout for CP Series Panels with 9 Pin Connectors



Pin #	RS-232	RS-485	Current Loop
1	N.C.	+5V	+5V
2	RXD	N.C.	TX-
3	TXD	GND	GND
4	DTR	TX+	N.C.
5	GND	TX-	N.C.
6	N.C.	N.C.	RX+
7	RTS	N.C.	RX-
8	CTS	RX+	N.C.
9	N.C.	RX-	TX+

The programming port on all panels is RS-232. The PLC communications port can be either RS-232, RS-485, or 20 mA current loop.

Technical assistance may be obtained :
In North America EXOR at 1-513-874-4665
In Europe EXOR Italy at +39 045 - 8779068