UniOP with a Compumotor Motion Controller

When using a UniOP panel with a Compumotor motion controller, the following five lines *must* be present at the beginning of the motion control program in order for proper initialization.

ERRBAD13,10,63,32
ERRDEF13,10,45,32
ERROK13,10,62,32
ECHO0
ERRLVL3

Technical assistance may be obtained :
In North America EXOR at 1 -513-874-4665
In Europe EXOR Italy at +39 045 - 8779068