

# FBS-PLC User's Manual 【*Hardware*】

## Contents

### Chapter 1 : Introduction of FATEK FBS Series PLC

1.1	Appearance of Main Unit .....	H1-1
1.2	Appearance of Expansion Unit/Module.....	H1-2
1.3	Appearance of Communication Expansion Module .....	H1-4
1.4	List of FBS-PLC Models .....	H1-5
1.5	Specifications of Main Unit.....	H1-8
1.6	Environmental Specifications .....	H1-9
1.7	Connection Diagrams of Various Models .....	H1-10
1.7.1	NC Control Main Unit (MN) .....	H1-10
1.7.2	Basic/Advanced Main Unit (MA/MC) .....	H1-11
1.7.3	Digital I/O Expansion Unit.....	H1-13
1.7.4	Digital I/O Expansion Module.....	H1-14
1.7.5	High-Density Digital I/O Expansion Module .....	H1-15
1.7.6	Numeric I/O Expansion Module.....	H1-15
1.7.7	Analog I/O Expansion Module .....	H1-15
1.7.8	Temperature Input Module.....	H1-16
1.7.9	AI/AO/Temperature Combo Module .....	H1-17
1.7.10	Expansion Power Module .....	H1-17
1.7.11	Voice Output Module .....	H1-17
1.7.12	Potential Meter Module .....	H1-17
1.7.13	Load Cell Module .....	H1-17
1.7.14	Communication Module (CM) .....	H1-18
1.7.15	Communication Board (CB).....	H1-19
1.7.16	Analog Expansion Board .....	H1-20
1.7.17	Simple HMI.....	H1-20
1.8	Drawings with External Dimensions .....	H1-21

### Chapter 2 : System Configuration

2.1	Single-Unit System of FBS-PLC.....	H2-1
-----	------------------------------------	------

2.2	Formation of Multi-Unit System.....	H2-2
2.2.1	Connection of Multiple FBs-PLC (CPU Link).....	H2-2
2.2.2	Connection of FBs-PLC with Host Computer or Intelligent Peripherals.....	H2-3

## Chapter 3 : Expansion of FBs-PLC

3.1	I/O Expansion .....	H3-1
3.1.1	Digital I/O Expansion and I/O Numbering.....	H3-1
3.1.2	Numeric I/O Expansion and I/O Channel Mapping.....	H3-3
3.2	Expansion of Communication Port .....	H3-5

## Chapter 4 : Installation Guide

4.1	Installation Environment.....	H4-1
4.2	PLC Installation Precautions .....	H4-1
4.2.1	Placement of PLC .....	H4-1
4.2.2	Ventilation Space.....	H4-2
4.3	Fixation by DIN RAIL.....	H4-3
4.4	Fixation by Screws .....	H4-4
4.5	Precautions on Construction and Wiring.....	H4-6

## Chapter 5 : Power Supply Wiring, Power Consumption Calculation, and Power Sequence Requirements

5.1	Specifications and Wiring of AC Power Sourced Power Supply .....	H5-1
5.2	Specifications and Wiring of DC Power Sourced Power Supply .....	H5-2
5.3	Residual Capacity of Main/Expansion Unit and Current Consumption of Expansion Module .....	H5-4
5.3.1	Residual Capacity of Main/Expansion Unit .....	H5-4
5.3.2	Maximum Current Consumption of Expansion Module .....	H5-5
5.3.3	Calculation Example of Power Capacity .....	H5-7
5.4	Requirement of Power Sequence in Main Unit and Expansion Unit/Module .....	H5-9

## Chapter 6 : Digital Input (DI) Circuit

6.1	Specifications of Digital Input (DI) Circuit.....	H6-1
6.2	Structure and Wiring of 5VDC Ultra High Speed Differential Input Circuit .....	H6-2
6.3	24VDC Single-End Input Circuit and Wiring for SINK/SOURCE Input .....	H6-3

## Chapter 7 : Digital Output (DO) Circuit

7.1	Specifications of Digital Output Circuit.....	H7-2
7.2	5VDC Ultra High Speed Line-Driver Differential Output Circuit and its Wiring .....	H7-3
7.3	Single-End Output Circuit .....	H7-3
7.3.1	Structure and Wiring of Single-End Relay Output Circuit .....	H7-3
7.3.2	Structure and Wiring of Single-End Transistor SINK & SOURCE Output Circuit.....	H7-4
7.4	Speed up the Single-End Transistor Output Circuit (only applicable to high and medium-speed) .....	H7-6
7.5	Output Device Protection and Noise Suppression in DO Circuit .....	H7-6
7.5.1	Protection of Relay Contacts and Noise Suppression .....	H7-6
7.5.2	Protection of Transistor Output and Noise Suppression.....	H7-8

## Chapter 8 : Test Run, Monitoring and Maintenance

8.1	Inspection After Wiring and Before First Time Power on.....	H8-1
8.2	Test Run and Monitoring .....	H8-1
8.3	LED Indications on PLC Main Unit and Troubleshooting .....	H8-2
8.4	Maintenance .....	H8-4
8.5	The Charge of Battery & Recycle of Used Battery .....	H8-4

# **【*Instruction*】**

## **Contents**

### **Chapter 1: PLC Ladder Diagram and the Coding Rules of Mnemonic**

1.1	The Operation Principle of Ladder Diagram.....	1-1
1.1.1	Combination Logic.....	1-1
1.1.2	Sequential Logic.....	1-2
1.2	Differences Between Conventional and PLC Ladder Diagram.....	1-3
1.3	Ladder Diagram Structure and Terminology.....	1-5
1.4	The Coding Rules of Mnemonic.....	1-8
1.5	The De-Composition of a Network.....	1-11
1.6	Using Temporary Relays.....	1-12
1.7	Program Simplification Techniques.....	1-13

### **Chapter 2: FBS-PLC Memory Allocation**

2.1	FBS-PLC Memory Allocation.....	2-1
2.2	Digital and Register Allocations.....	2-2
2.3	Special Relay Details.....	2-3
2.4	Special Registers Details.....	2-7

### **Chapter 3: FBS-PLC Instruction Lists**

3.1	Sequential Instructions.....	3-1
3.2	Function Instructions.....	3-2

### **Chapter 4: Sequential Instructions**

4.1	Valid Operand of Sequential Instructions.....	4-1
4.2	Element Description.....	4-2
4.2.1	Characteristics of A, B, TU and TD Contacts.....	4-2
4.2.2	OPEN and SHORT Contact.....	4-3
4.2.3	Output Coil and Inverse Output Coil.....	4-4
4.2.4	Retentive Output Coil.....	4-4
4.2.5	Set Coil and Reset Coil.....	4-5
4.3	Node Operation Instructions.....	4-5

## Chapter 5: Description of Function Instructions

5.1	The Format of Function Instructions.....	5-1
5.1.1	Input Control.....	5-1
5.1.2	Instruction Number and Derivative Instructions .....	5-2
5.1.3	Operand.....	5-3
5.1.4	Functions Output (FO).....	5-6
5.2	Use Index Register(XR) for Indirect Addressing .....	5-6
5.3	Numbering System.....	5-9
5.3.1	Binary Code and Related Terminologies .....	5-9
5.3.2	The Coding of Numeric Numbers for FBS-PLC.....	5-10
5.3.3	Range of Numeric Value.....	5-10
5.3.4	Representation of Numeric Value .....	5-10
5.3.5	Representation of Negative Number .....	5-11
5.3.6	Representation of Floating Point Number .....	5-11
5.4	Overflow and Underflow of Increment(+1) or Decrement(-1) .....	5-12
5.5	Carry and Borrow in Addition/Subtraction .....	5-13

## Chapter 6: Basic Function Instructions

●	T	(Timer) .....	6-2
●	C	(Counter) .....	6-5
●	Set	(SET) .....	6-8
●	Reset	(RESET) .....	6-10
●	Master control loop start	(FUN0) .....	6-12
●	Master control loop end	(FUN01) .....	6-14
●	Skip start	(FUN02) .....	6-15
●	Skip end	(FUN03) .....	6-17
●	Differential up	(FUN04) .....	6-18
●	Differential down	(FUN05) .....	6-19
●	Bit shift	(FUN06) .....	6-20
●	Up/down counter	(FUN07) .....	6-21
●	Move	(FUN08) .....	6-23
●	Move inverse	(FUN09) .....	6-24
●	Toggle switch	(FUN10) .....	6-25
●	Addition	(FUN11) .....	6-26
●	Subtraction	(FUN12) .....	6-27

● Multiplication	(FUN13) .....	6-28
● Division	(FUN14) .....	6-30
● Increment	(FUN15) .....	6-32
● Decrement	(FUN16) .....	6-33
● Compare	(FUN17) .....	6-34
● Logical and	(FUN18) .....	6-35
● Logical or	(FUN19) .....	6-36
● Binary to bcd conversion	(FUN20) .....	6-37
● Bcd to binary conversion	(FUN21) .....	6-38

## Chapter 7:Advanced Function Instructions

● Flow Control Instructions I	(FUN22) .....	7-1
● Arithmetical Operation Instructions	(FUN23~33) .....	7-2 ~ 7-18
● Multiple Linear Conversion	(FUN34) .....	7-19 ~ 7-24
● Logical Operation Instructions	(FUN35~36) .....	7-25 ~ 7-26
● Comparison Instruction	(FUN37) .....	7-27
● Data Movement Instructions I	(FUN40~50) .....	7-28 ~ 7-38
● Shifting/Rotating Instructions	(FUN51~54) .....	7-39 ~ 7-42
● Code Conversion Instructions	(FUN55~64) .....	7-43 ~ 7-59
● Flow Control Instructions II	(FUN65~71) .....	7-60 ~ 7-67
● I/O Instructions I	(FUN74~86) .....	7-68 ~ 7-84
● Cumulative Timer Instructions	(FUN87~89) .....	7-85 ~ 7-86
● Watchdog Timer Instructions	(FUN90~91) .....	7-87 ~ 7-88
● High Speed Counting/Timing	(FUN92~93) .....	7-89 ~ 7-90
● Report Printing Instructions	(FUN94) .....	7-91 ~ 7-92
● Slow Up/Slow Down Instructions	(FUN95~98) .....	7-93 ~ 7-98
● Table Instructions	(FUN100~114) .....	7-99 ~ 7-117
● Matrix Instructions	(FUN120~130) .....	7-118 ~ 7-129
● I/O Instruction II	(FUN139) .....	7-130 ~ 7-131
● NC Positioning Instructions I	(FUN140~143) .....	7-132 ~ 7-135
● Enable/Disable Instructions	(FUN145~146) .....	7-136 ~ 7-137
● NC Positioning Instructions II	(FUN147~148) .....	7-138 ~ 7-139
● Communication Instructions	(FUN150~151) .....	7-140 ~ 7-141
● Data Movement Instructions II	(FUN160~162) .....	7-142 ~ 7-147
● In Line Comparison Instructions	(FUN170~175) .....	7-148 ~ 7-153
● Other Instructions	(FUN190) .....	7-154 ~ 7-155
● Floating Point Instructions	(FUN200~220) .....	7-156 ~ 7-177

## Chapter 8: Step Instruction Description

8.1	The Operation Principle of Step Ladder Diagram .....	8-1
8.2	Basic Formation of Step Ladder Diagram .....	8-2
8.3	Instruction of Step Instructions: STP, FROM, TO, and STPEND .....	8-5
8.4	Notes for Writing a Step Ladder Diagram .....	8-11
8.5	Application Examples .....	8-15
8.6	Syntax Check Error Codes for Step Instruction .....	8-22

## **【Appendix I】** FBs-PACK Operation Instruction

1.1	Write Ladder Program and Register Data to FBs-PACK with WinProladder .....	1
1.2	Write Ladder Program and Register Data to FBs-PACK with Special Register Operation .....	4
1.3	Assigning the Retrieval of Register Stored FBs-PACK .....	6
1.4	Read and Write FBs-PACK by Function Instruction .....	7